

# HP 618 Digital Camera

HP Imaging Technology



# User's Guide

© Copyright 2000 Hewlett-Packard Company. ALL RIGHTS RESERVED.

The information contained in this document is subject to change without notice. Hewlett-Packard Company shall not be liable for errors contained herein or for consequential damages in connection with the furnishing, performance, or use of this material. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

HP, the HP logo, JetSend, the JetSend logo, PhotoSmart, and the PhotoSmart logo are property of Hewlett-Packard Company.

PENTAX is a trademark of Asahi Optical Co., Ltd.

The Digita camera operating system is © copyright 2000 FlashPoint Technology, Inc. ALL RIGHTS RESERVED.

Digita and the Digita logo are trademarks of FlashPoint Technology, Inc.

SanDisk and CompactFlash are trademarks of SanDisk Corporation.

Adobe and Acrobat are registered trademarks of Adobe Systems Incorporated.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Apple, Macintosh, and Mac are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

Chapter 1: Introduction .....	5
Product Overview .....	5
What's in this Guide .....	6
How to Use this Guide .....	7
Related Information .....	7
Chapter 2: Preparing to Take Pictures .....	8
Accessing the Capture Mode and Powering on the Camera .....	8
Using the Status LCD .....	9
Using the Image LCD .....	12
Chapter 3: Taking Pictures .....	16
Taking Simple Point-and-Shoot Pictures .....	16
Taking More Advanced Pictures .....	17
Using the Zoom Lever .....	22
Using the Diopter Control .....	22
Understanding the LEDs on the Camera .....	23
Using Instant Review .....	25
Recording Sound .....	26
Chapter 4: Viewing and Reviewing Images .....	27
Using Playback Mode .....	27
Using Review Mode .....	30
Chapter 5: Sharing Images .....	38
Transferring Images to Your Computer .....	38
Using a Digital Print Order Format (DPOF) File .....	44
JetSending Images to a Printer .....	46
Transmitting Images Between Two Cameras .....	48
Connecting the Camera to Your Television .....	50
Chapter 6: Menu and Soft Key Reference .....	52
Capture Mode Menus and Soft Keys .....	52
Playback Mode Menu and Soft Keys .....	74
Review Mode Menus and Soft Keys .....	78

Chapter 7: Troubleshooting .....	88
Troubleshooting Common Problems .....	88
Contacting HP Customer Care .....	93
Appendix A: Using the Preferences Menu .....	94
Accessing the Preferences Menu .....	94
Setting the Display .....	95
Controlling Camera Sounds .....	97
Formatting the Memory Card .....	98
Selecting the PC Connect Mode .....	98
Setting the Date and Time .....	99
Setting the Image Counter .....	100
Naming Your Camera .....	101
Selecting a Language .....	102
Resetting Camera Settings .....	102
Appendix B: Camera and Accessories Information .....	103
Camera Specifications .....	103
Battery Life .....	106
HP Accessories for Powering the Camera .....	107
Storage Capacities of Memory Cards .....	109
Appendix C: Product Warranties .....	110
Limited Product Warranty .....	110
Hewlett-Packard Year 2000 Warranty .....	112
Appendix D: Product Safety and Regulatory Information .....	113
Safety Information .....	113
Regulatory Notices .....	114
Glossary .....	115
Index .....	125



**Note:** For more detailed information about the camera’s features, see “Camera Specifications” on page 103.

**Note:** Capture, Playback, and Review modes have menus and related soft keys you can use to change your camera’s settings and to edit and organize images. (PC Connect mode does not have menus or soft keys.)

Welcome to the *HP 618 Digital Camera User’s Guide*. This guide will help you take high-quality pictures quickly and easily with your HP 618 digital camera.

## Product Overview

The HP 618 is a versatile, point-and-shoot digital camera. It provides these key features:

- ◆ HP Imaging Technology
- ◆ 3x optical /2x digital zoom
- ◆ Three image type settings – One Shot, Continuous, and Timelapse
- ◆ Two focus modes – Auto and Manual
- ◆ Three auto focus range settings – Normal, Macro, and Infinity
- ◆ Six exposure settings – Auto, Landscape Program, Portrait Program, Action Program, Aperture Priority, and Shutter Priority
- ◆ Built-in flash with seven flash modes – Auto, Auto with Red-Eye Reduction, Forced On, Forced On with Red-Eye Reduction, Forced Off, Night, and Night with Red-Eye Reduction
- ◆ Three timer modes – Off, 10-Second Timer, and 3-Second Remote

Your camera comes equipped with four operating modes (see Table 1). To set the mode, turn the camera mode dial on top of the camera to the mode you want to use.

**Table 1: Camera Modes**

Mode	Use this Mode to...
 <b>Capture</b>	Take pictures (or “capture images”).
 <b>Playback</b>	View the captured images in a variety of ways. You can view images full screen, play back timelapse and grouped image sequences, and create slideshows of images.
 <b>Review</b>	Sort and edit the captured images in a variety of ways. For example, you can group, categorize, delete, and search for captured images.
<b>PC PC Connect</b>	Transfer images from the camera to a computer.

## What's in this Guide

This *User's Guide* provides all the “how to” and reference information you need to use your camera successfully.

Part of Manual	What is Covered
“Chapter 2: Preparing to Take Pictures”	How to adjust settings in the status LCD, image LCD, and Capture mode menus to prepare your camera to take pictures.
“Chapter 3: Taking Pictures”	How to take simple point-and-shoot pictures, as well as more advanced pictures. Also how to use the zoom, Instant Review, and the sound recording features.
“Chapter 4: Viewing and Reviewing Images”	How to view images full screen, play back timelapse and grouped image sequences, and create slideshows of images in Playback mode. Also how to edit, organize, delete, and search for images in Review mode.
“Chapter 5: Sharing Images”	How to share images by transferring them to your computer, JetSending them to a printer, transmitting them to other cameras and printers, and viewing them on a television.
“Chapter 6: Menu and Soft Key Reference”	What each of your camera's menus and related soft keys do.
“Chapter 7: Troubleshooting”	How to fix common problems when using the camera, and how to contact HP Customer Care for help, if needed.
“Appendix A: Using the Preferences Menu”	How to use the Preferences menu to change a variety of your camera's general settings.
“Appendix B: Camera and Accessories Information”	Specifications for the camera, as well as information about some of the accessories that the camera supports.
“Appendix C: Product Warranties”	Limited product warranty and the HP Year 2000 warranty for the camera.
“Appendix D: Product Safety and Regulatory Information”	Safety information and regulatory notices regarding the camera and some of its accessories.
“Glossary”	Definitions of the terms related to your camera that are used throughout this guide and in the camera's <i>Quick Start Guide</i> .
“Index”	Where to find particular topics about your camera throughout this guide.

**Note:** If you choose to print this guide, be aware that printing it in color may take a long time. Therefore, you may want to print this guide in black and white, instead.

**Note:** It is assumed that you have already used the *HP 618 Digital Camera Quick Start Guide* to install the batteries and the memory card in your camera.

## How to Use this Guide

You can use this guide online, or you can print it out. The main advantage of using it online is that you can use its built-in searching and linking capabilities on your computer to quickly find the information you need. Of course, an advantage of having a print-out is that you can take it anywhere you want to use your camera. You may also prefer to read information about your camera from a printed version, rather than on a computer screen.

This online guide is provided in Adobe® Acrobat® version 4.0 (.pdf) format. To learn how to use Acrobat's searching and linking features, see the online Help for the Acrobat software.

To print this guide, select **Print** from Acrobat's File menu. In the Print dialog box, either click the **OK** button to print the entire guide, or specify the **Print Range** of pages you want and then click **OK**.

## Related Information

For a complete listing and description of your camera's features, including diagrams showing the locations of all the buttons, dials, displays, and so on, see the printed *HP 618 Digital Camera Quick Start Guide* that was included with your camera. Along with helping you use your camera for the first time to capture and view images, the *Quick Start Guide* also explains how to transfer images from the camera to your computer.

To learn how to use the software that came with your camera, see the software's online Help. All the documentation for the software is provided in the form of online Help within the software itself.

Finally, you can get project ideas, troubleshooting assistance, and up-to-date information about your camera and the HP Photo Imaging Software from the HP website at: [www.hp.com/photosmart](http://www.hp.com/photosmart). Updates for your camera's firmware are also posted to this website from time-to-time. You can install these updates on your camera so that you can always have the most current functionality running on it.

### Overview

You can use your camera's default settings to take pictures in a point-and-shoot fashion, or you can use more advanced features that you set via the camera's status LCD and image LCD. This chapter explains how to prepare your camera to take pictures by adjusting various settings on it.

This chapter covers the following topics:

- ◆ “Accessing the Capture Mode and Powering on the Camera” on page 8
- ◆ “Using the Status LCD” on page 9
  - ◆ “Setting the Flash Mode” on page 10
  - ◆ “Setting the Timer Mode” on page 11
  - ◆ “Setting the Auto Focus Range” on page 11
- ◆ “Using the Image LCD” on page 12
  - ◆ “Setting the Image Type” on page 13
  - ◆ “Understanding the Text Message Area” on page 12
  - ◆ “Viewing the Camera Status” on page 14
  - ◆ “Using the Overlay Soft Key” on page 14
  - ◆ “Using the Capture Mode Menus” on page 15
  - ◆ “Using the 4-Way Controller” on page 15

### Accessing the Capture Mode and Powering on the Camera

To prepare your camera to take pictures, you must first set your camera to Capture mode and power on the camera:


- 1 Turn the camera mode dial on the top of the camera to  (see Figure 1).
- 2 Power on the camera by sliding the ON/OFF power switch on the back of the camera to the right and releasing it. The status LCD on the top of the camera turns on and displays the status of the camera.

**Figure 1:** Setting the Camera to Capture Mode



## Using the Status LCD

**Figure 2:** Status LCD Indicators



The status LCD conveys important information about the camera's status. The status LCD shows you the status of the camera's batteries, the settings for the flash mode, timer mode, and auto focus range, as well as the number of pictures remaining on the memory card (see Figure 2).

The status LCD turns on every time you power on the camera. You can use the status LCD to assess the current status of the camera, and to change the flash mode, timer mode, and auto focus range settings when preparing to take pictures.

The buttons beneath the status LCD – the flash mode button , the timer mode button , and the auto focus range button  – toggle the associated camera settings on and off within the status LCD (see Figure 3). To change one of these settings, press the associated button until you see the desired icon or set of icons displayed in the status LCD for the setting you want.

The next three subsections explain the possible settings for the flash mode, timer mode, and auto focus range on the camera.

**Figure 3:** Status LCD Buttons



Flash mode    Timer mode    Auto focus range

**Note:** If you see 000 flashing in the status LCD, this means that either there is no memory card in the camera, or the memory card is full.

## Setting the Flash Mode

Your camera has seven flash modes. The default flash mode is Auto (no icons displayed). Each mode is displayed on the status LCD with the icon(s) shown in Table 2. To set the flash mode, press the flash mode button  beneath the status LCD to toggle through the icons on the status LCD until you see the flash mode setting you want (see Table 2).

**Note:** The flash mode setting remains set between shots, but will return to Auto after you cycle the power on the camera (power it off and then on again).

If the batteries' charge is low, the camera will not take a picture if the flash mode is set to Forced On or Night, and it will disable the flash if set to Auto.

Also note that flash pictures may be over-exposed when using the Macro auto focus range (see "Setting the Auto Focus Range" on page 11). Thus, you may want to turn off the flash (set the flash mode to Forced Off) when taking pictures with the Macro auto focus range setting.

**Table 2: Flash Mode Settings**

Flash Mode	Icon Displayed	When to Use
Auto (default)	No Icon	To allow the camera to determine the need for flash based on the lighting conditions.
Auto with Red-Eye Reduction		To allow the camera to determine the need for flash based on the lighting conditions. When flash is used, red-eye reduction minimizes the occurrence of red-eye in pictures of people or animals by flashing twice.
Forced On		To use the flash, regardless of the lighting conditions.
Forced On with Red-Eye Reduction		To use the flash, regardless of the lighting conditions. Red-eye reduction minimizes the occurrence of red-eye in pictures of people or animals by flashing twice.
Forced Off		To take pictures without flash, regardless of the lighting conditions.
Night		To use a slow sync mode of the flash in which the camera collects the image background with the available light and flashes to illuminate the foreground of the image.
Night with Red-Eye Reduction		To use a slow sync mode of the flash in which the camera collects the image background with the available light and flashes to illuminate the foreground of the image. Red-eye reduction minimizes the occurrence of red-eye in pictures of people or animals by flashing twice.

**Note:** The 10-Second Timer mode is disabled for the Timelapse image type. (See “Setting the Image Type” on page 13.)

**Note:** After each timed exposure in 10-Second Timer mode, the camera will default to the Off timer mode setting. You must reset the timer to take another timed picture. In contrast, the 3-Second Remote timer mode setting remains set shot-to-shot.

**Note:** The auto focus range remains set between shots, but returns to Normal after you cycle the power on the camera (power it off and then on again).

If you change the focus mode from Auto to Manual Focus in the Photo Assist menu (see “Using the Capture Mode Menus” on page 15), the auto focus range is cancelled.

If you set the camera to the Macro auto focus range, the image LCD will turn on. This is because you will be unable to frame an image properly in the viewfinder due to parallax error.

Finally, if the camera cannot focus when set to the Normal auto focus range, it will make a “best guess” at the focus and take the picture. However, if it cannot focus when set to Macro, it will *not* take a picture.

## Setting the Timer Mode

Your camera has three timer modes. The default timer mode is Off. Each mode is displayed on the status LCD with the icon shown in Table 3. To set the timer mode, press the timer mode button  beneath the status LCD to toggle through the icons on the status LCD until you see the timer setting you want (see Table 3).

**Table 3: Timer Mode Settings**

Timer Mode	Icon Displayed	When to Use
Off (default)	No Icon	To take pictures without using the timer.
10-Second Timer		To take a picture 10 seconds after pressing the shutter release button.
3-Second Remote		To use the remote infrared trigger on the HP Remote Control (included with the camera), which has a 3-second delay.

## Setting the Auto Focus Range


You can choose from three auto focus ranges that are available via the status LCD. The default auto focus range is Normal. Each range setting is displayed on the status LCD with the icon shown in Table 4. To set the auto focus range, press the auto focus range button  beneath the status LCD to toggle through the icons on the status LCD until you see the setting you want (see Table 4).

**Table 4: Auto Focus Range Settings**

Auto Focus Range	Icon Displayed	When to Use
Normal (default)	No Icon	To take a picture of a subject that is within the normal focus range (neither close-up nor in the distance). The focus range is set from 0.5 meters to infinity.
Macro		To take a close-up picture of a subject, such as a flower. The focus range is set from 0.1 to 0.6 meters.
Infinity		To take a picture of a subject in the distance, such as a mountain range. The focus range is set at infinity.

## Using the Image LCD

**Figure 4:** Image LCD Screen in Live View



**Note:** By default, the image LCD is turned off when you power on the camera in Capture mode. If you want the image LCD to always turn on instead, you can change the setting in the Display submenu of the Preferences menu. (See “Display Submenu” on page 67 and “Setting the Display” on page 95.)

However, note that the image LCD uses a lot of battery power. If you are running your camera on batteries rather than with the HP-approved AC power adapter, you may want to limit your use of the image LCD.

**Note:** For information on setting the Exposure Mode, see “Exposure Mode Submenu” on page 56.

**Note:** For information on setting the Focus Mode, see “Focus Mode Submenu” on page 59.

Turn the image LCD on by pressing the DISPLAY button on the back of the camera. You now see the live view of Capture mode on the image LCD. Live view lets you preview the pictures you can take with the camera, as well as view and change some of the camera’s settings.

The image LCD screen in the live view of Capture mode includes two opaque overlay bars and an image area in the center for viewing your picture subjects (see Figure 4). The top overlay bar displays status information about the camera while you are taking pictures. The bottom overlay bar contains labels that describe the function of the soft keys immediately below them. For example, if you press the right (Status) soft key in Capture mode, the Status screen displays. To turn the overlay bars off or on, press the middle (Overlay) soft key.

You can also use the image LCD to access menus to change camera settings in the Capture, Playback, and Review modes, and to play back and review captured images in the Playback and Review modes, respectively. The image LCD is disabled in PC Connect mode.

The following subsections provide more information about the overlay bars and the soft keys in the live view of Capture mode.

### Understanding the Text Message Area

The text message area is a one-line text area in the middle of the top overlay bar. An example text message is: “Battery Low.” The following indicators will also appear in the text message area when you change certain settings in the Capture mode menus. For information on using the Capture mode menus to change camera settings, see “Using the Capture Mode Menus” on page 15.

### Exposure Mode Indicator

When you set the Exposure Mode in the Photo Assist menu to either Landscape Program, Portrait Program, or Action Program, the current Exposure Mode is displayed in the text message area.

### Aperture Value and Shutter Speed Indicators

When you set the Exposure Mode in the Photo Assist menu to Aperture Priority (Av) or Shutter Priority (Tv), the current aperture value and shutter speed are displayed in the text message area (for example: Tv 1/125 F5.6). The aperture value and shutter speed will update automatically and change continually as the camera zooms and measures the exposure. When the camera cannot set the correct exposure because you have selected an aperture or shutter speed that is too big or small, the line in the text message area will turn red.

### Manual Focus Distance

When you set the Focus Mode in the Photo Assist menu to Manual Focus, the focus distance appears on the left side of the text message area.

## Macro and Infinity Auto Focus Range Indicators

When the auto focus range is set to Macro, a Macro icon  is displayed on the right side of the text message area. When the auto focus range is set to Infinity, INF is displayed.

## Digital Zoom Indicator

When the camera is in digital zoom, the digital zoom icon  is displayed on the right side of the text message area. For information on digital zooming, see “Using the Zoom Lever” on page 22.

## Setting the Image Type

Your camera can take three types of pictures (that is, three “image types”):

- ◆ One Shot
- ◆ Continuous
- ◆ Timelapse

The image type is displayed at the left side of the bottom overlay bar in the live view of Capture mode. Image type settings are listed in Table 5. The default image type is One Shot. To set the image type, press the left soft key to toggle through the types until you see the image type setting you want (see Table 5).

**Note:** For the Timelapse image type, you can set the number of images that will be captured and the interval between them in the Timelapse Settings submenu of the Capture Settings menu. (See “Timelapse Settings Submenu” on page 54.)

Also note that if the interval you set for Timelapse image capture is long, the camera may go into sleep mode (shutting off the image LCD) between taking pictures to conserve battery power.

Finally, if you set the Timelapse interval to 15 or 30 sec and you have the File Type set to TIFF, the camera may skip capturing an image if it is not finished processing the previous image in the Timelapse sequence.

**Table 5: Image Type Settings**

Image Type	When to Use	How to Use
One Shot (default) 	When capturing a single image.	Press and release the shutter release button to capture a single image.
Continuous 	When capturing a series of images in rapid succession. Recommended for action shots.	Hold the shutter release button down. Continuous images are captured until you release the button or until the memory card is full.
Timelapse 	When capturing a slow process with a series of images.	Press and release the shutter release button, and the camera captures the first image. Then it displays a countdown to the next image capture on the top overlay bar. To cancel, press the Stop soft key.

## Using the Overlay Soft Key

Press the middle (Overlay) soft key to turn both overlay bars off in the live view of Capture mode. To turn the overlay bars on again, press *any* of the three soft keys. When the overlay bars are off, the soft keys are disabled for their normal functions and are, instead, enabled only to turn the overlay bars on again.

## Viewing the Camera Status

You can press the right (Status) soft key while in the live view of Capture mode to display the Status screen (see Figure 5). This screen allows you to check the current camera status, such as the current resolution, quality, and white balance settings. (To change these settings, use the Capture mode menus. See the next subsection for details.) One or more icons may also appear on the Status screen, including:

- ◆  means that a memory card is inserted in the camera.
- ◆  means that the current auto focus range setting is Macro.
- ◆  shows the battery status.

The following status information is provided:

Resolution	Resolution setting for capturing images (Full Size or 1/4)
Quality	Quality setting for capturing images (Good, Better, or Best for the JPEG file type, or TIFF for the TIFF file type)
White Balance	Color correction setting to make white areas appear white with no color cast
EV Comp	Exposure Value compensation setting for exposure control
ISO Speed	ISO Speed setting
AE Metering	Auto Exposure Metering setting
Version	The version number of your camera's firmware

To exit the Status screen and return to the live view of Capture mode, press the right (Exit) soft key.


Figure 5: Status Screen



**Note:** For more information about all of the Capture mode menus and related soft keys, see “Chapter 6: Menu and Soft Key Reference” starting on page 52.

For more information about the Preferences menu, see “Appendix A: Using the Preferences Menu” starting on page 94.

**Figure 6:** Parts of a Menu



## Using the Capture Mode Menus

Your camera has four Capture mode menus:

- ◆ Capture Settings
- ◆ Photo Assist
- ◆ Image Stamp
- ◆ Preferences

The Capture Settings, Photo Assist, and Image Stamp menus have settings you can change which affect the images you capture. The Preferences menu allows you to change a variety of your camera's general settings.

To access the Capture mode menus:

- 1 Set the camera mode dial to Capture mode .
- 2 Power on the camera if you haven't already.
- 3 Press the MENU button on the back of the camera. The Capture mode menus are displayed on the image LCD (see Figure 6).
- 4 Press the right or left arrow on the 4-way controller to move across the menu icon bar to access a particular menu. (See the next subsection, “Using the 4-Way Controller.”)
- 5 Press the down or up arrow on the 4-way controller to move the highlight to the menu option you want to select.
- 6 Press the left soft key to select the highlighted menu option.

**Figure 7:** 4-Way Controller



## Using the 4-Way Controller

The 4-way controller is the large button located on the back of your camera (see Figure 7). Press an arrow on the 4-way controller to move in the direction of that arrow (up, down, right, or left) in the image LCD, such as within the menu structures of the Capture, Review, or Playback modes.

### Overview

Once you have set your camera to Capture mode and you have a basic understanding of how to use your camera's status LCD and image LCD (see "Chapter 2: Preparing to Take Pictures" starting on page 8), you are ready to take pictures. To optimize your camera's capabilities, it is important to understand how to use the zoom lever, what the various LEDs mean when they light solid or blink, how to use Instant Review, and how to use the sound recording features when taking pictures.

This chapter covers the following topics:

- ◆ "Taking Simple Point-and-Shoot Pictures" on page 16
- ◆ "Taking More Advanced Pictures" on page 17
  - ◆ "Using Focus Lock" on page 18
  - ◆ "Shooting a One Shot Image" on page 19
  - ◆ "Shooting Continuous Images" on page 20
  - ◆ "Shooting Timelapse Images" on page 21
- ◆ "Using the Zoom Lever" on page 22
- ◆ "Using the Diopter Control" on page 22
- ◆ "Understanding the LEDs on the Camera" on page 23
- ◆ "Using Instant Review" on page 25
- ◆ "Recording Sound" on page 26

### Taking Simple Point-and-Shoot Pictures

Here is the simplest method for taking pictures with your camera:

- 1 Set the camera mode dial to the Capture mode .
- 2 Power on the camera if you haven't already.
- 3 Look through the viewfinder to select and frame a subject for your picture.

**Note:** These instructions for taking simple point-and-shoot pictures assume that your camera is set to the default image type (One Shot), and that Instant Review is on as well. (See "Setting the Image Type" on page 13 and "Using Instant Review" on page 25 for more information.)

- 4 Press the shutter release button. Wait for the shutter sound, indicating the camera has captured the image. Then release the button.

The captured image appears for a 3-second Instant Review period on the image LCD. If you are happy with it, do nothing, and the image will be saved on the memory card. If not, you can delete the image while it is still displayed in Instant Review by pressing the middle (Delete) soft key.

## Taking More Advanced Pictures

As explained in Chapter 2: “Preparing to Take Pictures,” your camera has more advanced features that you can set via your camera’s status LCD and image LCD. Here is the general procedure for taking more advanced pictures:

- 1 Set the camera mode dial to the Capture mode .
- 2 Power on the camera if you haven’t already.
- 3 Set the flash mode, timer mode, and/or the auto focus range via the status LCD buttons on the top of the camera, as desired. (For information on these settings, see “Using the Status LCD” on page 9.) The settings you choose are displayed in the status LCD.
- 4 Press the DISPLAY button on the back of the camera to turn the image LCD on.
- 5 Press the left soft key to set the image type (One Shot, Continuous, or Timelapse). (For more information, see “Setting the Image Type” on page 13.) The image type you choose is displayed on the left side of the bottom overlay bar in the image LCD.
- 6 Press the MENU button on the back of the camera to display the Capture mode menus on the image LCD, if you wish to change any of the default camera settings in the menus.
- 7 Select the menu options you wish to change in the Capture Settings, Photo Assist, and/or Image Stamp menus, and then make the changes to the camera settings within those menus, as desired. (For information about changing settings in these Capture mode menus, see “Capture Mode Menus and Soft Keys” on page 52.)

For example, if you have set the camera to the Timelapse image type, then you might want to change the default settings in the Timelapse menu option of the Capture Settings menu. In this case, you could change the number of images and/or the interval between them for the time-lapse sequence that you want to shoot.

**Note:** The image LCD uses a lot of battery power. If you are running your camera on batteries rather than with the HP-approved AC power adapter, you may want to limit your use of the image LCD and use the viewfinder instead. To turn the image LCD off, press the DISPLAY button on the back of the camera.

- 8 Press the right (Exit) soft key to exit the Capture mode menus.
- 9 Use the image LCD or the viewfinder to select and frame the subject for your picture. If needed, use the zoom lever (see page 22) to adjust the focal length of the camera lens to zoom in or out on the picture subject. You can also use the diopter control (see page 22) when looking through the viewfinder to adjust the focus of the picture subject in the viewfinder. Note that the diopter control has no effect on the image you capture, however.

If you cannot obtain focus on your picture subject, see the next subsection, “Using Focus Lock.” Otherwise, go on to the “What’s Next?” subsection.

## Using Focus Lock

If you cannot obtain focus on your picture subject, use Focus Lock as follows to get the proper focus:

- 1 If the main subject of your picture is:
  - ◆ Not within the center of the viewfinder frame or image LCD screen, center the main subject of your picture in the center of the viewfinder frame or image LCD screen. Go on to step 2.
  - ◆ Near a very bright or dark area, or is behind another object (such as a screen or fence) which overlaps the subject, focus the camera on another object the same distance from you as the subject. Go on to step 2.
- 2 Press the shutter release button halfway down *and continue to hold it halfway down*. This locks the focus.
- 3 Without releasing the shutter release button, recompose the picture as you originally wanted it, and then press the shutter button all the way down to take the picture. (Also see the following subsections for how to take pictures for each image type.)

## What’s Next?

What you need to do next to actually take a picture depends on the image type you have selected, and whether or not you have set a timer mode. The following subsections describe how to capture the image(s), as well as what occurs once you do, for each image type setting.

## Shooting a One Shot Image

If you are using the:

- ◆ **Shutter release button with no timer mode set**, press the shutter release button. Wait for the shutter sound, indicating the camera has captured the image. Then release the button.
- ◆ **10-Second Timer  mode**, press and release the shutter release button. The timer LED on the front of the camera (see page 24) lights solid for 7 seconds. It then blinks for the final 3 seconds before the camera captures the image.
- ◆ **3-Second Remote  timer mode**, point the HP Remote Control at the camera, and press and release the Remote Control's trigger button. The timer LED on the front of the camera (see page 24) blinks faster for 3 seconds. Then the camera captures the image.

If Instant Review is on (see “Using Instant Review” on page 25), you can do any of the following while the image you just captured is displayed in Instant Review on the image LCD:

- ◆ Record sound that will be attached to this image. For information on how to do this, see “Recording Sound” on page 26.
- ◆ Delete the image by pressing the middle (Delete) soft key.
- ◆ Save the image to the memory card and return to the Capture mode *immediately* by pressing the right (Exit) soft key.
- ◆ Do nothing and, when Instant Review times out (the default time-out is 3 seconds), the image is then saved to the memory card automatically.

**Note:** If you set the timer mode to 10-Second Timer or 3-Second Remote for the Continuous image type, you can only take one picture. Therefore, to capture a Continuous sequence of images, use the shutter release button with no timer mode set (that is, with the timer mode set to its default Off setting).

**Note:** If Instant Review is on, each image in a Continuous sequence *except for the final one* is automatically saved to the memory card before the camera captures the next image in the sequence. If Instant Review is off, each image is automatically saved before the next one is captured, and then the final one is saved automatically, as well.

Also note that, unlike Timelapse images, Continuous images are not grouped together but are individual images. Thus, they are saved as individual images on the memory card.

**Note:** If you are unhappy with any other images within a Continuous sequence (rather than just the final image, which you can only delete during Instant Review), you can delete those images in the Review mode. To do this, see “Deleting Images” on page 32.

## Shooting Continuous Images

Press the shutter release button and *continue to hold the button down*. Then the camera begins to capture the images in the Continuous sequence.

Continuous images are captured until you release the shutter release button, or the memory card becomes full, whichever comes first.

The camera will capture images as fast as it can. The capture rate (that is, the time between pictures) will vary depending on the processing required (for such things as the resolution and image quality settings) before each image is saved to the memory card (see the second Note on the left). The capture rate also depends on whether or not the flash is being charged between shots. If you wish to increase the capture rate of Continuous images, you can turn the live view of Capture mode off by pressing the DISPLAY button on the back of the camera, turn Instant Review off through the Display menu option in the Preferences menu of Capture mode (see “Display Submenu” on page 67), and set the flash mode to Forced Off (see “Setting the Flash Mode” on page 10).

If Instant Review is on (see “Using Instant Review” on page 25), at the end of taking a Continuous sequence of images, the *final* image of the sequence is displayed in the Instant Review on the image LCD. You can do any of the following during the Instant Review period:

- ◆ Record sound that will be attached to the *final* image of the sequence. For information on how to do this, see “Recording Sound” on page 26.
- ◆ Delete the *final* image of the sequence by pressing the middle (Delete) soft key. (All of the other images in the sequence were already saved to the memory card.)
- ◆ Save the *final* image of the sequence to the memory card and return to the Capture mode *immediately* by pressing the right (Exit) soft key. (All of the other images in the sequence were already saved to the memory card.)
- ◆ Do nothing and, when Instant Review times out (the default time-out is 3 seconds), the *final* image of the sequence is then saved to the memory card automatically.

**Note:** The 10-Second Timer mode is disabled for the Timelapse image type.

**Note:** If the interval you set for Timelapse image capture is long, the camera may go into sleep mode (shutting off the image LCD) between taking pictures to conserve battery power.

Also, if you set the Timelapse interval to 15 or 30 sec and you have the File Type set to TIFF, the camera may skip capturing an image if it is not finished processing the previous image in the Timelapse sequence.

**Note:** If you are unhappy with one or more images within a Timelapse sequence, you can delete only those images in the Review mode (rather than deleting *all* of the images in the sequence during Instant Review). To do this, see “Deleting Images” on page 32.

**Note:** All images in a Timelapse sequence are saved as one group on the memory card.

## Shooting Timelapse Images

If you are using the:

- ◆ **Shutter release button with no timer mode set**, press and release the shutter release button *one time*. Then the camera captures the first image of the Timelapse sequence.
- ◆ **3-Second Remote  timer mode**, point the HP Remote Control at the camera, and press and release the Remote Control’s trigger button *one time*. The timer LED on the front of the camera (see page 24) blinks faster for 3 seconds. Then the camera captures the first image of the Timelapse sequence.

The settings in the Timelapse menu option of the Capture Settings menu determine the number of pictures that are taken and the interval between pictures in the Timelapse sequence of images that are captured. (To change the Timelapse settings, see “Timelapse Settings Submenu” on page 54.)

The image LCD displays the previously captured image while counting down to the next image capture. The only option you have is to stop the Timelapse sequence by pressing the right (Stop) soft key.

If Instant Review is on (see “Using Instant Review” on page 25), at the end of taking a Timelapse sequence of images, the *first* image in the sequence is displayed in the Instant Review on the image LCD. You can do any of the following during the Instant Review period:

- ◆ Record sound that will be attached to the *first* image of the sequence. For information on how to do this, see “Recording Sound” on page 26.
- ◆ Delete *all* of the images in the sequence by pressing the middle (Delete) soft key.
- ◆ Save *all* of the images in the sequence to the memory card and return to the Capture mode *immediately* by pressing the right (Exit) soft key.
- ◆ Do nothing and, when Instant Review times out (the default time-out is 3 seconds), *all* of the images in the sequence are then saved to the memory card automatically.

### What’s Next?

The following sections provide more information about various features of your camera that you can use when taking pictures (such as the zoom), or that provide you with important feedback on the status of your camera while you are taking pictures (such as the LEDs). Once you have read through the following sections, continue on to Chapter 4 to learn how to view and review the images you have captured via the camera’s Playback and Review modes.

## Using the Zoom Lever

While you are framing the subject for a picture, you will likely find that you need to zoom in or out on the subject. This section explains the camera's zoom lever, which you can use for this purpose.

Rocking the zoom lever (see Figure 8) left and right moves the lens continuously between wide angle 🌳 and telephoto 🌲 focal lengths for optical zooming.

The zoom lever also controls digital zooming. Digital zooming refers to digital cropping of the image, giving the appearance of greater zoom. After the optical zoom is at its maximum setting, you can digitally zoom in three steps (see below). Note, however, that you must have the image LCD on for the digital zoom to operate. (To turn the image LCD on, press the DISPLAY button on the back of the camera.)

If the image LCD is turned on and the camera's zoom is at the end of the telephoto range, releasing and pressing the zoom lever will initiate digital zooming. A digital zoom icon 📐 will appear in the text message area of the image LCD's top overlay bar. Digital zooming occurs in three steps:


- ◆ 1.2x
- ◆ 1.5x
- ◆ 2x

The camera pauses for 250 milliseconds (1/4 second) between steps. Digital zoom remains set shot-to-shot, but turns off when you cycle the power on the camera. It also turns off any time you exit the live view of Capture mode (for example, you press the MENU button on the camera to display the Capture mode menus, or you turn the camera mode dial to set the camera to another mode). To exit the digital zoom, you can also press, release, and then re-press the zoom lever in the wide angle direction.

## Using the Diopter Control

The diopter control (see Figure 9) is the small dial on the left side of the viewfinder that you can turn to adjust the focus of the picture subject in the viewfinder. Note that the diopter control has no effect on the image you capture, however.

Figure 8: Zoom Lever



**Note:** In digital zoom mode, enlargement is accomplished without changes in the lens configuration. Since the lens is not involved in digital zoom, the changes appear only in the image LCD; they are *not* evident through the viewfinder.

Figure 9: Diopter Control



**Note:** The diopter control does *not* affect the captured image itself.

## Understanding the LEDs on the Camera

Your camera has several LEDs (Light Emitting Diodes) that light solid or blink to indicate that certain actions are occurring within the camera, or particular problems may have occurred while you were performing a particular task with the camera. This section describes what these LEDs are and how they behave.

### Viewfinder LEDs

The LEDs on the right side of the viewfinder (see Figure 10) display either a green light, red light, or both, indicating either the focus status, flash status, a memory card problem, or that the camera is processing an image and is not ready to take a picture.

Figure 10: Viewfinder LEDs




Table 6: Viewfinder LEDs

LED	Function	Behavior
Green (Top)	Indicates focus status	Lights solid when the shutter release button is pressed halfway down to indicate that the picture is ready to take.  Blinks when the camera cannot focus on the picture subject.
Red (Bottom)	Indicates flash status	Lights solid when the shutter release button is pressed halfway down to indicate that the flash is charged and ready to fire.  Blinks when the shutter release button is pressed halfway down to indicate that the flash is charging.
Both	Indicate a memory card problem, or that the camera is processing an image and is not ready to take a picture	In the event of a full or missing memory card, both LEDs blink when you press the shutter release button halfway down. In this case, 000 will also blink on the status LCD.  In the event of a bad or unformatted memory card, or when the camera is processing an image and is not ready to take a picture, both LEDs blink when you press the shutter release button halfway down.

**Figure 11:** Timer LED



**Figure 12:** Memory Card Access LED



**Caution:** Make sure the camera is powered *off* any time you remove the memory card from the camera. Removing the memory card when the memory card access LED is blinking could corrupt the images and other files on the memory card.

## Timer LED

The red timer LED on the front of the camera (see Figure 11) lights solid and/or blinks depending on the timer mode you set (see “Setting the Timer Mode” on page 11). If you set the timer mode to the:

- ◆ **10-Second Timer setting**, when you press and release the shutter release button, the timer LED lights solid for 7 seconds. It then blinks for the final 3 seconds before the camera captures the image.
- ◆ **3-Second Remote setting**, the timer LED blinks slowly while waiting for you to press the Remote Control’s trigger button. Once you press the trigger button, the timer LED blinks faster for 3 seconds before the camera captures the image.

## Memory Card Access LED

The amber memory card access LED on the back of the camera (see Figure 12) blinks whenever the camera is reading from or writing to the memory card.

## Using Instant Review

The Instant Review feature allows you to see displayed on the image LCD either the One Shot image, the final image of a Continuous image sequence, or the first image of a Timelapse sequence you just captured. The default setting is that Instant Review is on for 3 seconds after the One Shot image or the final image in a Continuous or Timelapse sequence is captured.

You can change the duration that the image is displayed in Instant Review or turn Instant Review off through the Display menu option in the Preferences menu of Capture mode. (See “Display Submenu” on page 67 and “Setting the Display” on page 95.)

While an image is displayed in Instant Review on the image LCD, you can do any of the following:

- ◆ Record sound that will be attached either to the One Shot image, to the *final* image of a Continuous sequence, or to the *first* image of a Timelapse sequence (see the next section, “Recording Sound”).
- ◆ Delete the captured image(s) by pressing the middle (Delete) soft key. Either the One Shot image, the *final* image of a Continuous sequence, or *all* of the images in a Timelapse sequence will be deleted.

When you press the Delete soft key, you will be prompted Delete? in the top overlay bar. You can press either the left (Delete) soft key to delete the image(s), or the right (Cancel) soft key to cancel the delete operation. If you recorded sound, then the option of deleting Sound Only is also provided for the middle soft key.

- ◆ Save the image(s) to the memory card and return to the Capture mode *immediately* by pressing the right (Exit) soft key. Either the One Shot image, the *final* image of a Continuous sequence, or *all* of the images in a Timelapse sequence will be saved.
- ◆ Do nothing and, when Instant Review times out (the default time-out is 3 seconds), the image(s) are then saved to the memory card automatically. Either the One Shot image, the *final* image of a Continuous sequence, or *all* of the images in a Timelapse sequence will be saved.

**Note:** When Instant Review is set to Off, the camera immediately returns to Capture mode, and the captured image or sequence of images is automatically saved to the memory card.


**Note:** If you are unhappy with any other images within a Continuous sequence (rather than just the final image, which you can only delete during Instant Review), you can delete those images in the Review mode. To do this, see “Deleting Images” on page 32.

Similarly, if you are unhappy with one or more images within a Timelapse sequence, you can delete only those images in the Review mode (rather than deleting *all* of the images in the sequence during Instant Review). To do this, see “Deleting Images” on page 32.

**Note:** You can record up to 45 seconds of sound per image or sequence of images.

**Note:** The microphone is located on the front of the camera. So if you are recording your own voice, you may get better sound quality by rotating the camera around to face you.

**Figure 13:** Screen During Sound Recording



**Note:** You can also record sound to attach to a One Shot image, any of the images in a Continuous sequence, or to the first image in a Timelapse sequence of images after the Instant Review period has finished. To do so, you must set the camera to either Playback  or Review  mode. Then select an image or sequence of images in the Playback or Review mode and follow steps 1-4 (to the right on this page) to record sound that will be attached to the selected image or sequence of images.

## Recording Sound

You can record sound to attach to your images when your camera is in Capture mode and has Instant Review set on (see the previous section). During the Instant Review period, the camera records the sound and then attaches it to either the One Shot image, to the *final* image of a Continuous sequence, or to the *first* image of a Timelapse sequence that you just captured. The sound recording capability remains active during the entire Instant Review period.

You can also record sound in the Playback or Review modes to attach to images. (See the second Note on the left for more information.)

Once you have captured an image or sequence of images in Capture mode and the Instant Review is displayed on the image LCD, do the following to record sound that will be attached to the image:

- 1 Press the sound record button  on the back of the camera to activate the recording. A microphone icon flashes and the length of the recording in minutes and seconds (00:00) appears in the top overlay bar of the image LCD (see Figure 13).
- 2 Record your sound (up to 45 seconds).
- 3 Press the sound record button again to stop the recording. The screen displays Ready in the top overlay bar, and three soft key labels in the bottom overlay bar: Play, Delete, and Exit (from left to right).
- 4 Do any of the following:
  - ◆ Press the left (Play) soft key to play back the sound recorded.
  - ◆ Press the middle (Delete) soft key to delete either the image(s) and the sound, or to delete the sound only.
  - ◆ Press the right (Exit) soft key to *immediately* save the image(s) and the attached sound to the memory card.
  - ◆ Do nothing and allow the Instant Review to time out. In this case, the image(s) and the attached sound are automatically saved to the memory card.

### Overview

This chapter explains how to view captured images via the Playback mode and how to review the images via the Review mode.

This chapter covers the following topics:

- ◆ “Using Playback Mode” on page 27
  - ◆ “Accessing the Playback Mode” on page 27
  - ◆ “Viewing Images Full Screen” on page 28
  - ◆ “Understanding the Overlay Bars” on page 28
  - ◆ “Turning the Overlay Bars Off and On” on page 28
  - ◆ “Zooming in on Images” on page 28
  - ◆ “Playing Back Timelapse and Grouped Images” on page 28
  - ◆ “Creating and Playing a Slideshow” on page 29
  
- ◆ “Using Review Mode” on page 30
  - ◆ “Accessing the Review Mode” on page 30
  - ◆ “Selecting Images” on page 30
  - ◆ “Marking and Unmarking Images” on page 31
  - ◆ “Expanding and Collapsing Timelapse or Grouped Images” on page 31
  - ◆ “Deleting Images” on page 32
  - ◆ “Grouping Images and Dissolving Image Groups” on page 33
  - ◆ “Protecting and Unprotecting Images” on page 34
  - ◆ “Categorizing Images and Deselecting Image Categories” on page 35
  - ◆ “Searching for Images by Date and by Category” on page 36

**Note:** You cannot delete images while in Playback mode. You can delete images in Review mode, however. (See “Deleting Images” on page 32.)

### Using Playback Mode

#### Accessing the Playback Mode

To access the Playback mode:

- 1 Set the camera mode dial to Playback mode .
  
- 2 Power on the camera if you haven't already. The Playback mode screen is displayed on the image LCD.

**Note:** You can change the playback rate in the Playback Rate submenu of the Play Settings menu. For more information, see “Playback Rate Submenu” on page 76.

## Viewing Images Full Screen

When you first enter Playback mode, the image LCD displays the last image saved on the memory card. The image appears full screen. To view a full screen image of the other captured images on the memory card, press the right or left arrow on the 4-way controller to scroll through the images.

## Understanding the Overlay Bars

The Playback mode displays two overlay bars. The top overlay bar contains information about the image (including the image number, the date and time the image was captured, as well as some of the key camera settings that were used to capture the image, such as the image type and exposure mode). The bottom overlay bar contains the soft key labels.

## Turning the Overlay Bars Off and On

By default, both the top and bottom overlay bars are displayed in Playback mode. However, you can turn one or both overlay bars off so you can see more of each image on the image LCD. Simply press the DISPLAY button on the back of the camera once to turn both overlay bars off, a second time to turn the bottom one on only, and a third time to turn both on again.

## Zooming in on Images

If you want to see a portion of an image in more detail, press the middle (Zoom) soft key. When you are zoomed in, you can use the 4-way controller to see different parts of the image. You must then zoom out by pressing the middle (Zoom Out) soft key before moving to a different image.

## Playing Back Timelapse and Grouped Images

You can play back sequences of Timelapse and grouped images at a pre-defined rate, much like a slideshow.

To play back image sequences:

- 1 Use the 4-way controller to scroll to the Timelapse or grouped images you want to play back.
- 2 Press the left (Play) soft key. The images, including any sound you have attached to them, will play back on the image LCD.
- 3 Press the left (Stop) soft key to stop playing back your images.

## Creating and Playing a Slideshow

You can create a slideshow to display your images on the image LCD or on a television screen. Your slideshow can include all of the images on the memory card, or you can choose a single category of images to use.

For more information on:

- ◆ Categories, see “Categorizing Images and Deselecting Image Categories” on page 35.
- ◆ Connecting your camera to a television so that you can view a slideshow on the television, see “Connecting the Camera to Your Television” on page 50.

To create and play a slideshow:

- 1** Press the MENU button on the back of the camera. The Slideshow option of the Play Settings menu is highlighted.
- 2** Press the left (Edit) soft key to go to the Slideshow submenu.
- 3** Change any of the settings in the Slideshow submenu, as desired. For more information about these settings, see “Slideshow Submenu” on page 75.
- 4** Press the left (Start) soft key to begin the slide show.
- 5** You can stop the slideshow at any time by pressing the left (Stop) soft key.
- 6** After you have stopped the slideshow or it has ended, press the right (Exit) soft key to save the settings and exit the Slideshow menu.

## Using Review Mode

### Accessing the Review Mode

To access the Review mode:

- 1 Set the camera mode dial to Review mode .
- 2 Power on the camera if you haven't already.

The Review mode screen is displayed on the image LCD (see Figure 14). The image LCD displays the images that are saved on the memory card. The images appear as small thumbnails along the top of the screen.

The small thumbnail that has the selection marker under it is the selected image. The selected image is also displayed as the large thumbnail on the bottom left of the screen. Information about the selected image (including the image number and the date and time the image was captured) appears on the bottom right of the screen. If the selected image is a part of a group, the group name is also displayed. If the image was transmitted to this camera from another camera, and the other camera had a camera name assigned, then the camera name is displayed (instead of any group name).


The icon bar above the image information area shows whether the selected image is a single image, a collapsed Timelapse sequence of images, or a collapsed group of images. The icon bar also shows a sound icon if sound is attached to the selected image, as well as a category icon if a category has been assigned to the selected image.

### Selecting Images

The selection marker beneath the small thumbnail row indicates which image is selected and is displayed as the large thumbnail, along with its image information, at the bottom of the screen.

To select an image, press the right or left arrow on the 4-way controller to scroll through the thumbnails until the selection marker is under the image that you want to select. The selected image is now displayed as the large thumbnail, along with its image information, at the bottom of the screen.

**Figure 14:** Image LCD Screen in Review Mode



## Marking and Unmarking Images

You can mark several images so that, when you select an action from the Review mode menus, that action will apply to all the marked images. For example, you can mark several images and delete them all at once, instead of having to delete one image at a time.

To mark or unmark *all* of the images on the memory card, press and hold the left (Mark or Unmark) soft key for 3 seconds, and then release it.

To mark one or more (but not all) images:

- 1 Press the right or left arrow on the 4-way controller to scroll through the thumbnails until the selection arrow is under an image you want to mark.
- 2 Press the left (Mark) soft key. A notch appears in the lower right corner of the selected thumbnail image (see Figure 15).
- 3 Repeat steps 1 and 2 to mark additional images.

To unmark an image, scroll to the marked image, and then press the left (Unmark) soft key.

## Expanding and Collapsing Timelapse or Grouped Images

When you take Timelapse pictures, the camera takes a sequence of pictures and automatically groups the captured images, using the first captured image to represent the sequence. You can also group individual images using the Group menu option of the Review mode menus (see “Grouping Images and Dissolving Image Groups” on page 33). This section explains how to expand Timelapse or grouped images into the individual images, and how to collapse them again.

To expand Timelapse or grouped images:

- 1 Select the image that represents the Timelapse or grouped image sequence that you want to expand.
- 2 Press the right (Expand) soft key. Thumbnails of all the images in the sequence are displayed with links between them (see Figure 16).

To collapse Timelapse or grouped images:

- 1 Select any image in the Timelapse sequence or group you want to collapse.
- 2 Press the right (Collapse) soft key.

**Figure 15:** A Marked Image



**Figure 16:** An Expanded Group



**Note:** To mark or unmark *all* of the images on the memory card, press and hold the left (Mark or Unmark) soft key for 3 seconds, and then release it.

**Note:** Protected images will not be deleted. See “Protecting and Unprotecting Images” on page 34.

## Deleting Images

You can delete a single image that is currently selected (whether it is a One Shot or Continuous image, an individual image within an expanded Timelapse sequence, or an individual image within an expanded group of images), all marked images, a collapsed Timelapse sequence of images, or a collapsed group of images from the memory card.

To delete images:

- 1 Select the image or mark the images you want to delete.

If you want to delete one or more images (but not *all* the images) within a Timelapse sequence or a group of images, first follow the instructions in “Expanding and Collapsing Timelapse or Grouped Images” on page 31 to expand the Timelapse sequence or group of images. Then select the image or mark the images you want to delete from the expanded Timelapse sequence or group of images.

- 2 If you want to:

- ◆ Delete only the currently selected single image, collapsed Timelapse sequence of images, or collapsed group of images, press the middle (Delete) soft key in the Review mode screen.
- ◆ Delete all of the marked images, press the MENU button on the back of the camera. The Edit menu of Review mode is displayed, with the Delete menu option highlighted. Press the middle (Delete) soft key.

- 3 Press the left (Delete) soft key again to delete the image(s).

**Note:** A group becomes a folder on the memory card, in which all the images in that group are stored.

**Note:** Group names must be eight characters or less, and cannot contain spaces. Also, the camera does not accept group names that begin with BR or TL (regardless of language) because these letters are reserved.

**Figure 17:** Two Images in a Group



**Note:** Dissolving a group does *not* delete the images in the group, only the group name.

## Grouping Images and Dissolving Image Groups

You can group images to organize them in one folder on the memory card. To group images:

- 1 Mark the images you wish to group.
- 2 Press the MENU button on the back of the camera. The Edit menu of Review mode is displayed.
- 3 Press the down arrow on the 4-way controller to scroll to the Group menu option.
- 4 Move to the Group Name menu by pressing either the left (Create) soft key if there are no existing groups, or the left (Add) soft key and then the middle (Create New) soft key if there are existing groups.
- 5 Name the new group by doing the following. (See the Note on the left for restrictions on group names.)
  - ◆ Press the up or down arrow on the 4-way controller to scroll to the letter you want to use.
  - ◆ Press the right arrow on the 4-way controller to add a letter to the name, or the left arrow to delete a letter. For example, if you select the letter “L” and then press the right arrow on the 4-way controller, the letter appears in the center of the screen.
- 6 Press the right (Exit) soft key to exit the Group Name menu, and then press Exit again to exit the Review mode menus. You are returned to the Review mode screen. The name of the group now appears in the image information for all the images in the group when each image is selected, and the images in the group have a link icon between them (see the example in Figure 17).

To dissolve (remove) the grouping on images:

- 1 Select any image included in the group you want to dissolve.
- 2 Press the MENU button on the back of the camera. The Edit menu of Review mode is displayed.
- 3 Press the down arrow on the 4-way controller to scroll to the Group menu option.
- 4 Press the center (Dissolve) soft key to dissolve (remove) the grouping.
- 5 Press the right (Exit) soft key. You are returned to the Review mode screen, and the images are no longer grouped.

## Protecting and Unprotecting Images

You can protect images so that they won't be deleted accidentally. (When an image is protected, it cannot be deleted from the memory card.)

To protect images:

- 1 Select an image or mark the images you want to protect.
- 2 Press the MENU button on the back of the camera. The Edit menu of Review mode is displayed.
- 3 Press the down arrow on the 4-way controller to scroll to the Protect menu option.
- 4 Press the center (Protect) soft key. You are returned to the Review mode screen, and a Protect icon appears in the image information for the protected image(s) (see Figure 18).

To remove protection from (unprotect) images:

- 1 Select an image or mark the images you want to unprotect.
- 2 Press the MENU button.
- 3 Press the down arrow on the 4-way controller to scroll to the Protect menu option.
- 4 Press the left (Unprotect) soft key. You are returned to the Review mode screen, and there is no longer a Protect icon in the image information for the image(s).

**Figure 18:** A Protected Image



## Categorizing Images and Deselecting Image Categories

You can assign a category to your images to make them easier to find and organize. You can also play a slideshow of a category of images very easily.

You can either categorize one image at a time, or mark a number of them and apply one category to all of the marked images.

To categorize one or more images:

- 1 Select or mark the image(s) you wish to categorize.
- 2 Press the MENU button on the back of the camera. The Edit menu of Review mode is displayed.
- 3 Press the down arrow on the 4-way controller to scroll to the Categorize menu option.
- 4 Press the left (Edit) soft key to move to the Categories submenu.
- 5 Press the down arrow on the 4-way controller to scroll to the category you want to assign to the image(s).
- 6 Press the left (Select) soft key. A checkmark appears next to that category, and you are returned to the Review mode screen. An icon representing the category you assigned to the image(s) now appears in the image information for the selected image(s) (see Figure 19).

**Figure 19:** A Categorized Image



To deselect an image's category:

- 1 Select the image whose category you want to deselect.
- 2 Press the MENU button on the back of the camera. The Edit menu of Review mode is displayed.
- 3 Press the down arrow on the 4-way controller to scroll to the Categorize menu option.
- 4 Press the left (Edit) soft key to move to the Categories submenu.
- 5 Press the down arrow on the 4-way controller to scroll to the category you want to deselect.
- 6 Press the left (Deselect) soft key. You are returned to the Review mode screen, and the category icon is no longer in the image information for the selected image.

## Searching for Images by Date and by Category

You can use the Find menu in Review mode to search for images by date or by category. For more information on categories, see “Categorizing Images and Deselecting Image Categories” on page 35.


To search for images by date:

- 1 Press the MENU button on the back of the camera. The Edit menu of Review mode is displayed.
- 2 Press the right arrow on the 4-way controller to scroll to the Find menu.
- 3 Press the left (Edit) soft key.
- 4 Enter the range of dates you want the camera to use to search for images (see Figure 20):
  - ◆ Press the right arrow of the 4-way controller to scroll to the month, day, and year fields.
  - ◆ Press the up and down arrows to change the month, day, and year.
- 5 Press the left (Find) soft key. The results of your search appear on the image LCD (see Figure 21). Notice the Find icon at the bottom right of the screen, which indicates that the displayed images are the result of a Find operation.
- 6 Press the arrows on the 4-way controller to scroll through the images. When you are done, press the center (Show All) soft key to resume viewing all the images stored on the memory card.

Figure 20: Find By Date



Figure 21: Results of a Find by Date Operation



**Note:** If there are no images within the range of dates that you specified, the image LCD displays the message: “No images matched search criteria.” In this case, you can either press the middle (Show All) soft key to resume viewing all images stored on the memory card, or press the left (Find) soft key to select a new range of dates.

To search for images by category:

- 1 Press the MENU button on the back of the camera. The Edit menu of Review mode is displayed.
- 2 Press the right arrow on the 4-way controller to scroll to the Find menu.
- 3 Press the down arrow on the 4-way controller to scroll to By Category.
- 4 Press the left (Edit) soft key.
- 5 Press the down arrow on the 4-way controller to scroll to the category you want to view.
- 6 Press the left (Select) soft key. The results of your search appear on the image LCD. Notice the Find icon at the bottom right of the screen, which indicates that the displayed images are the result of a Find operation.
- 7 Press the arrows on the 4-way controller to scroll through the images. When you are done, press the center (Show All) soft key to resume viewing all the images stored on the memory card.

### Overview

You can use the images you capture with your camera in many fun and creative ways. You can transfer them to your computer for use in creative projects, or for sharing with family and friends via the Internet. If you have a printer that supports the HP JetSend infrared technology, you can use JetSend for wireless printing of your images. You can even connect the camera to your television to view a slideshow of your images on the television.

This chapter covers the following topics:

- ◆ “Transferring Images to Your Computer” on page 38
- ◆ “Using a Digital Print Order Format (DPOF) File” on page 44
- ◆ “JetSending Images to a Printer” on page 46
- ◆ “Transmitting Images Between Two Cameras” on page 48
- ◆ “Connecting the Camera to Your Television” on page 50

### Transferring Images to Your Computer

You can transfer images to your computer when the camera is set to PC Connect mode. The PC Connect Mode submenu of the Preferences menu lets you specify how the camera will appear to your computer when connected via the USB interface. You can set the camera to one of the following settings in the PC Connect Mode submenu depending on the operating system that is running on your computer:

PC Connect Mode	How Images are Transferred	Operating Systems
Digita™ Device (default)	You can use software included with your computer or camera to transfer images to the computer.	Windows® Me, 98, and 2000
USB Disk Drive	The camera is operated as a USB Mass Storage Device and appears as a disk drive connected to your computer. So you can copy images from your camera to the computer as you would from another disk drive.	Mac® OS 8.6 or better, and Windows Me, 98, and 2000

**Caution:** Be aware that any sound (namely, sound tags and other EXIF tags) you have captured and attached to images with your camera may not be supported and may be lost if you use image editing software other than the HP Photo Imaging Software with the images on your computer.


The one exception is Windows NT 4.0, because it does not support the USB interface. A Windows NT 4.0 computer must have either an HP P1000/1100 or similar printer, or a memory card reader connected to its serial or parallel interface. You can then transfer images from the camera's memory card to the computer via either the memory card slot in the HP printer, or the memory card reader.

The following three subsections explain how to transfer images to a computer depending on the PC Connect Mode setting on the camera and/or the operating system that is running on the computer:

- ◆ To use the Digita Device setting to transfer images from your camera to a Windows Me, 98, or 2000 computer, see the first subsection below.
- ◆ To use the USB Disk Drive setting to transfer images from your camera to either a Macintosh® computer running Mac OS 8.6 or better, or a Windows Me, 98, or 2000 computer, see the subsection on page 41.
- ◆ To transfer images from the memory card to a Windows NT 4.0 computer, see the subsection on page 43.

**Note:** If you have a Windows 98 or 2000 computer, it is assumed in this subsection that you have already followed the *HP 618 Digital Camera Quick Start Guide* to install the HP Photo Imaging Software on your computer.

**Figure 22:** Connectors on the USB Cable



## Transferring Images Using the Digita Device Setting

If your computer is running Windows Me, 98, or 2000, you can transfer images from your camera to the computer by using the default Digita Device setting in the PC Connect Mode submenu. If your camera is running:

- ◆ **Windows Me**, you can then use the Microsoft® Scanner and Camera Wizard that is included on your Windows Me system to transfer the images from the camera to your computer.
- ◆ **Windows 98 or 2000**, you can then use the HP Photo Imaging Software that came with your camera to transfer the images from the camera to your computer.

To transfer images to your Windows Me, 98, or 2000 computer, do the following:

- 1 Power *off* the camera if it is still on.
- 2 Power *on* the computer if you haven't already.
- 3 Connect the *rectangular* end of the USB cable to the USB port on the front or back exterior of your computer (see Figure 22).

**Figure 23:** Connecting the USB Cable to the Camera



- 4 Open the door to the camera's connector compartment and connect the *square* end of the USB cable to the bottom (USB) connector (see Figure 23).
- 5 Set the camera to PC Connect mode **PC**.
- 6 Power *on* the camera. Within a few seconds, your computer detects the camera on the USB port. What happens next depends on what version of Windows your computer is running:

<b>Windows Me</b>	Your computer runs the Microsoft Scanner and Camera Wizard. Follow the prompts in the Wizard to copy the images to your computer.
<b>Windows 98 or 2000</b>	The main window of the HP Photo Imaging Software opens. Do the following: <ol style="list-style-type: none"><li>1. Click <b>Unload Camera</b> in the main window.</li><li>2. Click the <b>Start</b> button in the Unload Images window. The images are copied to your computer.</li></ol>

**Note:** If you have a Macintosh computer and have already followed the instructions in the *HP 618 Digital Camera Quick Start Guide* to set the USB Disk Drive mode on your camera, skip these instructions and go on to “Using Your Camera as a USB Mass Storage Device to Transfer Images” on page 42.

## Transferring Images Using the USB Disk Drive Setting

If your computer is running either Macintosh OS 8.6 or better, or Windows Me, 98, or 2000, you can transfer images from your camera to the computer by using the USB Disk Drive setting in the PC Connect Mode submenu. In so doing, the camera will operate as a USB Mass Storage Device and appear as a disk drive connected to your computer. You can then copy images from your camera to the computer as you would from another disk drive. The following two subsections explain how.

### Setting the USB Disk Drive Mode on the Camera


You must first set your camera to USB Disk Drive mode as follows:

- 1 Set the camera mode dial to Capture mode .
- 2 Power *on* the camera if you haven't already.
- 3 Press the MENU button on the back of the camera. The Capture mode menus are displayed on the image LCD.
- 4 Press the right arrow on the 4-way controller three times to move to the Preferences menu.
- 5 Press the down arrow on the 4-way controller three times to move to the PC Connect Mode menu option.
- 6 Press the left (Edit) soft key. The PC Connect Mode submenu is displayed, and the USB Disk Drive option is highlighted.
- 7 Press the left (Select) soft key. The checkmark moves to the USB Disk Drive option, and you return to the Preferences menu of Capture mode. The camera is now set to USB Disk Drive mode.
- 8 Press the right (Exit) soft key to exit the menu.
- 9 Power *off* the camera by using the camera's power switch.

The USB Disk Drive mode will remain set on your camera *only* if you power off the camera by using the power switch. By powering off the camera correctly, you will *not* have to repeat the previous procedures when transferring images to your computer via the USB Disk Drive mode in the future.

**Note:** Software for Macintosh computers was included with your camera. If you wish, you can use this software to transfer images to your Macintosh, instead of the procedures here. This software also provides tools for editing images and using them in creative projects.

**Figure 24:** Connectors on the USB Cable



To Macintosh Keyboard  
or Windows Computer

To Camera

**Figure 25:** Connecting the USB Cable to the Camera



## Using Your Camera as a USB Mass Storage Device to Transfer Images

Once your camera is set to USB Disk Drive mode, you can transfer images to either your Macintosh OS 8.6 or better computer, or your Windows Me, 98, or 2000 computer, by doing the following:

- 1 Power *on* the computer if you haven't already.
- 2 Connect the *rectangular* end of the USB cable to the USB port on either your Macintosh computer's keyboard, or to the front or back exterior of your Windows computer (see Figure 24).
- 3 Open the door to the camera's connector compartment and connect the *square* end of the USB cable to the bottom (USB) connector (see Figure 25).
- 4 Set the camera mode dial to PC Connect mode **PC**.
- 5 Power *on* the camera. If you have a:
  - ◆ Macintosh computer, an icon labeled "Untitled" appears on your computer's desktop. The camera is now viewed by your Macintosh as a new disk drive.
  - ◆ A Windows computer, the camera appears as a removable disk drive connected to your computer under the My Computer folder in Windows Explorer.

If you have a Windows 98 or 2000 computer and have installed the HP Photo Imaging Software on your computer (by following the instructions in the *HP 618 Digital Camera Quick Start Guide*), then the main window of the HP Photo Imaging Software also opens. You can either follow step 6 below to copy the image files from the camera to the computer in Windows Explorer, or you can use the HP Photo Imaging Software to transfer the images.

- 6 Copy the image files from the disk drive (the camera) to the hard drive of your computer as you would from a floppy disk.

**Note:** It is assumed in this subsection that you have already followed the *HP 618 Digital Camera Quick Start Guide* to install the HP Photo Imaging Software on your computer.

## Transferring Images from a Memory Card to a Windows NT 4.0 Computer

To transfer images to your Windows NT 4.0 computer, you must have either an HP printer (such as the HP P1000/1100) that has a slot for reading a memory card, or a memory card reader connected to the computer's serial or parallel interface. (This is because Windows NT 4.0 does not support the USB interface.) You can then transfer images from the camera's memory card to your computer via either the HP printer's memory card slot, or the memory card reader.

**If you are using an HP printer that has a memory card slot,** refer to the printer's documentation to transfer images from the memory card to your Windows NT 4.0 computer via the printer's memory card slot.

**If you are using a memory card reader,** transfer images from the memory card to your Windows NT 4.0 computer as follows:

- 1 Power *off* the camera if it is still on.
- 2 Remove the memory card from the camera. To do this, open the memory card door and press the memory card release button to eject the card. Grasp the card by its side edges and pull it out of the slot.
- 3 Insert the memory card into the memory card slot in the memory card reader.
- 4 Power *on* the computer if you haven't already.
- 5 Double-click the HP Photo Imaging Software icon on the Windows desktop. The main window of the HP Photo Imaging Software opens.
- 6 Click **Unload Camera** in the main window. Because no USB camera is found, the software displays a dialog box in which you can select the drive letter for your memory card reader.
- 7 Select the drive letter (such as **H:**) for your memory card reader in the dialog box.
- 8 Click the **Start** button in the Unload Images window. The images are copied to your computer.

**Note:** If you delete an image that is referenced in a DPOF file on the memory card, you must erase and then re-create the DPOF file before you can print images via the DPOF file.

**Note:** For more information on the Print Order Form menu, see page 81.

## Using a Digital Print Order Format (DPOF) File

A DPOF file is a file you create using your camera that allows you to pre-select which images you want to print. The file is stored on the memory card and contains information about which images are selected, how many of each image is to be printed, and at what size to print each of them. The file is used by selected HP printers and other printing devices that can read a DPOF file directly from the memory card.

### Creating a DPOF File

To create a DPOF file:

- 1 Set the camera mode dial to Review mode .
- 2 Power on the camera if you haven't already.
- 3 Either select one image or mark multiple images in the Review mode screen that you want to include in the DPOF file. (See “Selecting Images” on page 30 and “Marking and Unmarking Images” on page 31 for more information.)
- 4 Press the MENU button on the back of the camera. The Review mode menus are displayed.
- 5 Press the right arrow on the 4-way controller once to move to the Print Order Form menu.
- 6 Press the left (Add) soft key to select the highlighted Add Images menu option. The Add to Order submenu is displayed.
- 7 Use the arrows on the 4-way controller to specify the number of Copies you want of the selected or marked images, as well as the Size you want them printed. The Size settings include:
  - ◆ Standard (default) – One of the standard print sizes. You specify the exact size you want your Standard prints to be at the printer. For example, you can specify that all Standard images be printed at 4” x 6”.
  - ◆ Index – Thumbnails of the images.
- 8 Press the left (Add) soft key to save the settings and return to the Print Order Form menu.

## Viewing a DPOF File

To view a DPOF file, do the following while in the Print Order Form menu:

- 1 Press the down arrow on the 4-way controller to highlight the View Order menu option.
- 2 Press the left (Select) soft key. The Print Order Form screen is displayed, which lists the contents of the DPOF file. You can scroll through this list using the up and down arrows on the 4-way controller. However, you cannot edit this list.

## Erasing a DPOF File

To erase a DPOF file, do the following while in the Print Order Form menu:

- 1 Press the down arrow on the 4-way controller to highlight the Erase Order menu option.
- 2 Press the left (Erase) soft key. You will see a confirmation of your choice to erase all entries from the Print Order Form.
- 3 Press the middle (Erase) soft key to erase all of the entries from the Print Order Form.

**Note:** It will take an average of 20 seconds to JetSend an image from the camera to a printer.



**Figure 26:** Infrared Window on the Camera

## JetSending Images to a Printer

HP JetSend allows for easy, wireless printing. If your printer supports the HP JetSend infrared technology, you can transfer your images directly from the camera to the printer without connecting any cables. See your printer's documentation for more information.

There are two different ways you can JetSend images to a printer. You can use the Send button  on the back of the camera to JetSend only the current image in the Capture, Playback, or Review mode to a printer. Or you can use the Transmit menu in Review mode to JetSend the current image or all marked images to a printer. Each of these methods is explained in the following subsections.

### Using the Send Button to JetSend Only the Current Image

To JetSend only the current image to a JetSend-capable printer:

- 1 Set the camera mode dial to either Capture , Playback , or Review  mode.
- 2 Power on the camera if you haven't already.
- 3 If you are in:
  - ◆ Capture mode, you will automatically be JetSending the last image you captured. You do not need to do anything to select the image.
  - ◆ Playback or Review mode, press the right or left arrow on the 4-way controller to scroll through your images in the Playback or Review mode screen until the image you want to transfer is displayed or selected.
- 4 Set your printer to receive images to print. See your printer's documentation for details.
- 5 Aim the camera's infrared window (see Figure 26) at the printer's infrared sensor, and place the camera about 10 inches away from the printer.
- 6 Press the Send button  on the back of the camera. The camera immediately starts a JetSend session, searches for a compatible printer, and sends the current image to the printer. (If the current image is actually a collapsed Timelapse sequence or group of images, only the first image of the sequence or group is sent.)

During the transfer, the image LCD reads: "Sending 1 image..." and shows a progress bar. You can cancel the transfer at any time by pressing the center (Stop) soft key on the camera. A confirmation screen will display to show that the Send was successful.
- 7 Press the right (Done) soft key when you have finished transmitting images to the printer.

## Using the Transmit Menu to JetSend the Current or All Marked Images

To JetSend the current image or all marked images to a JetSend-capable printer:

- 1 Set the camera mode dial to Review mode .
- 2 Power on the camera if you haven't already.
- 3 Either select one image or mark multiple images in the Review mode screen that you want to JetSend. (See “Selecting Images” on page 30 and “Marking and Unmarking Images” on page 31 for more information.)
- 4 Press the MENU button on the back of the camera. The Review mode menus are displayed.
- 5 Press the right arrow on the 4-way controller two times to move to the Transmit menu.
- 6 Press the down arrow on the 4-way controller to highlight the Camera-Printer menu option.
- 7 Set your printer to receive images to print. See your printer's documentation for details.
- 8 Aim the camera's infrared window (see Figure 26 on page 46) at the printer's infrared sensor, and place the camera about 10 inches away from the printer.
- 9 Press the left (Send) soft key on the camera. The camera immediately starts a JetSend session, searches for a compatible printer, and sends the current or all marked images to the printer. During the transfer, the image LCD reads: “Sending X image(s)...” and shows a progress bar. You can cancel the transfer at any time by pressing the middle (Stop) soft key on the camera. A confirmation screen will display to show that the Send was successful.
- 10 Press the right (Done) soft key when you have finished transmitting images to the printer.

## Transmitting Images Between Two Cameras

You can use the Camera-Camera option in the Transmit menu of Review mode to send images from your camera to another camera, or to receive images from another camera. The other camera must use the standard Digita transmit protocol. See the other camera's documentation for details.

### Sending Images to Another Camera

To send the current image or all marked images to another Digita camera:

- 1 Set the camera mode dial to Review mode .
- 2 Power on the camera if you haven't already.
- 3 Either select one image or mark multiple images in the Review mode screen that you want to send to the other camera. (See "Selecting Images" on page 30 and "Marking and Unmarking Images" on page 31 for more information.)
- 4 Press the MENU button on the back of the camera. The Review mode menus are displayed.
- 5 Press the right arrow on the 4-way controller two times to move to the Transmit menu. The Camera-Camera menu option is highlighted.
- 6 Press the left (Send) soft key on your camera. Your camera's image LCD reads: "Receiving Camera Ready?"
- 7 Set the other camera to receive images. See the other camera's documentation for details.
- 8 Aim your camera's infrared window (see Figure 26 on page 46) at the other camera's infrared sensor, and set the cameras about 10 inches apart.
- 9 Press the left (Continue) soft key on your camera. Your camera immediately searches for another compatible camera and begins to transmit images to the other camera.  
  
During the transfer, the image LCD reads: "Sending X image(s)..." and shows a progress bar. You can cancel the transfer at any time by pressing the middle (Stop) soft key on your camera. A confirmation screen will display to show that the transfer was successful.
- 10 Press the right (Done) soft key when you have finished transmitting images to the other camera.

## Receiving Images from Another Camera

To receive images from another Digital camera:

- 1 Set the camera mode dial to Review mode .
- 2 Power on the camera if you haven't already.
- 3 Press the MENU button on the back of the camera. The Review mode menus are displayed.
- 4 Press the right arrow on the 4-way controller two times to move to the Transmit menu. The Camera-Camera menu option is highlighted.
- 5 Press the middle (Receive) soft key on your camera.
- 6 Set the other camera to send images. See the other camera's documentation for details.
- 7 Aim your camera's infrared window (see Figure 26 on page 46) at the other camera's infrared sensor, and set the cameras about 10 inches apart.
- 8 Send the images from the other camera. See the other camera's documentation for details.
- 9 Press the right (Done) soft key when your camera has received all of the images.

**Note:** Your camera comes with a 6 ft. audio/video cable, which you can use to connect the camera to a television.

**Note:** Refer to your television's or VCR's documentation for more information about the video input format.

**Note:** See your television's documentation for specific instructions on how to locate the video input connector, and how to set the video input.

## Connecting the Camera to Your Television

When the camera is connected to a television, the television functions the same as the camera's image LCD. You can use your television to view a slideshow, making it easy to share your images with family and friends.

### Selecting the Camera's Video Output Format

Before you connect the camera to the television, you need to select the camera's video output format. The format that you choose (NTSC or PAL) depends on your television's video input format:

- ◆ NTSC is the video connection standard used in the United States and Japan.
- ◆ PAL is the video connection standard used in Europe.

To select the video output format for the camera:

- 1 Set the camera mode dial to Playback mode .
- 2 Power on the camera if you haven't already.
- 3 Press the MENU button on the back of the camera.
- 4 Press the down arrow on the 4-way controller to scroll to Video.
- 5 Press the left (Edit) soft key.
- 6 Press the right or left arrows on the 4-way controller to select NTSC or PAL in the Video Preferences submenu.

### Making the Connection

To connect the camera to the television:

- 1 Connect the video input end of the audio/video cable into your television:
  - ◆ If you are using an NTSC connection, plug the video input (yellow) end of the audio/video cable into your television's video input connector (on most televisions, this is also yellow).
  - ◆ If you are using a PAL connection, plug the video input (yellow) end of the audio video cable into your television's video input connector. On older television sets, plug the video cable into a SCART adapter (purchased separately), then plug the adapter into your television's video input connector.

**Note:** To conserve battery power, you may want to use an HP-approved AC power adapter to power the camera while you have it connected to a television.

**Figure 27:** Connecting the Video Cable to the Camera



**Note:** When the camera is connected to a television, the image LCD turns off.

- 2 Connect the audio input (red) end of the audio/video cable into the television's audio input connector. This will allow you to hear sound that you recorded and attached to your images.
- 3 Plug the other end of the video cable into the camera (see Figure 27).
- 4 On the television, set the video input to be the video input connector where you connected the camera.

## Viewing Images on the Television

When the camera is connected to a television, you can play or review your images on the television screen just as you would on the camera's image LCD. You can also mark, protect, categorize, group, or delete images, or create a slideshow.

To view images on a television:


- 1 Turn on the television and select the video input. See your television's documentation for specific instructions on how to select the video input.
- 2 Set the camera mode dial to either Playback mode  or Review mode .
- 3 View your images on the television using either Playback or Review mode.

The television functions the same as the camera's image LCD. You can use the buttons on the 4-way controller to scroll through your images, or press the MENU button on the back of the camera to use the camera menus on your television's screen.

**Note:** Updates for your camera's firmware are posted from time-to-time on the HP website at: [www.hp.com/photosmart](http://www.hp.com/photosmart). You can install these updates on your camera so that you can always have the most current functionality running on it.

**Note:** The PC Connect mode does *not* have any menus or soft keys; thus, that mode is not included in this chapter.

**Figure 28:** Capture Settings Menu



## Overview

This chapter contains a reference to all of the menus and soft keys you can use to make or adjust settings on your camera. This chapter is divided into three main sections, which correlate to the three camera modes that have menus and soft keys:

- ◆ “Capture Mode Menus and Soft Keys” on page 52
- ◆ “Playback Mode Menu and Soft Keys” on page 74
- ◆ “Review Mode Menus and Soft Keys” on page 78

## Capture Mode Menus and Soft Keys

To access the Capture mode menus and related soft keys, turn the camera mode dial to Capture mode  and press the MENU button on the back of the camera. You can choose options and settings from four Capture mode menus:

- ◆ “Capture Settings Menu” on page 52
- ◆ “Photo Assist Menu” on page 55
- ◆ “Image Stamp Menu” on page 62
- ◆ “Preferences Menu” on page 66

## Capture Settings Menu


Use the Capture Settings menu to specify characteristics of how to capture each image.

**Table 7:** Capture Settings Soft Keys


Soft Key	Function
Edit	Opens submenu associated with selected menu option.
Exit	Exits this menu and returns the camera to Capture mode.

**Note:** All options you set are active from shot-to-shot; they also remain set when you cycle the power on the camera.

**Figure 29:** File Settings Submenu - JPEG



**Figure 30:** File Settings Submenu - TIFF



**Note:** TIFF is an uncompressed file type used when you need the absolute best image quality. Because TIFF file size is very large, it may take up to 50 seconds to save the image.

## File Settings Submenu

Use the File Settings submenu to set how your pictures will be captured for all image types (One Shot, Continuous, and Timelapse).


**Table 8:** File Settings Submenu

Setting	Default	Options
File Type	JPEG	JPEG, TIFF
Quality Level (Specifies JPEG compression level and does <i>not</i> apply to TIFF images.)	Better	<p>Good - Produces quality images and uses less memory than the Better setting (uses the highest compression rate). Use this setting for images you plan to use on a computer, or to print photos of up to 4" x 6".</p> <p>Better - Produces high-quality images and uses less memory than the Best setting (uses a medium compression rate). Use this setting for images you plan to print photos of up to 5" x 7".</p> <p>Best - Produces the highest-quality images and uses the most memory (uses the lowest compression rate). Use this setting for images you plan to enlarge and print photos of up to 8" x 10".</p>
Resolution	Full Size	Full Size (1600 x 1200 pixels) 1/4 (800 x 600 pixels)
Color	Full	Full, B&W, Sepia

**Note:** “Storage Capacities of Memory Cards” on page 109 lists the number of images an 8 MB, 16 MB, and 32 MB memory card can store, depending on the JPEG quality level or TIFF setting at which the camera is set.

**Note:** All options you set are active from shot-to-shot; they also remain set when you cycle the power on the camera.

**Figure 31:** Timelapse Settings Submenu



**Note:** If you select more # Images than there is space on the memory card, you will see the error message “Not enough memory” on the overlay bar.

**Table 9:** File Settings Soft Keys

Soft Key	Function
Default	Returns all settings on screen to their defaults.
Exit	Saves the settings, exits this submenu, and returns the camera to the Capture Settings menu.

### Timelapse Settings Submenu

Use the Timelapse Settings submenu to specify the number and interval of images in a timelapse sequence.

**Table 10:** Timelapse Settings Submenu

Setting	Default	Options
# Images	2	2-1,000
Interval	15 seconds	Seconds - 15 sec, 30 sec Minutes - 1 min, 2 min, 3 min, 4 min, 5 min, 10 min, 15 min, 20 min, 30 min, 50 min Hours - 1 hr, 2 hr, 3 hr, 4 hr, 8 hr, 12 hr, 24 hr

**Table 11:** Timelapse Settings Soft Keys


Soft Key	Function
Default	Returns all settings on screen to their defaults.
Exit	Saves the settings, exits this submenu, and returns the camera to the Capture Settings menu.

## Photo Assist Menu

Use the Photo Assist menu to manipulate these more advanced camera operations:

- ◆ Exposure
- ◆ EV Compensation
- ◆ White Balance
- ◆ Focus
- ◆ AE Metering
- ◆ ISO Speed

**Figure 32:** Photo Assist Menu




**Table 12:** Photo Assist Soft Keys

Soft Key	Function
Edit	Opens submenu associated with highlighted menu option.
Exit	Exits this menu and returns the camera to Capture mode.

**Note:** The option you set is active from shot-to-shot; it resets to its default setting when you cycle the power on the camera.

**Figure 33:** Exposure Mode Submenu



## Exposure Mode Submenu

Use the Exposure Mode submenu to select how the camera calculates exposure. You can select from these setting options:

- ◆ **Auto (Default)** – All exposure settings are at their defaults and cannot be changed.
- ◆ **Landscape Program** – Automatically optimizes the camera settings for taking pictures of distant subjects, such as landscape scenes.
- ◆ **Portrait Program** – Automatically optimizes the camera settings for portrait photography.
- ◆ **Action Program** – Automatically optimizes the camera settings for taking pictures of subjects in action, such as people playing sports.
- ◆ **Aperture Priority (Av)** – Lets you select an aperture, and the camera automatically selects the shutter speed.
- ◆ **Shutter Priority (Tv)** – Lets you select a shutter speed, and the camera automatically selects the aperture setting.

If you select Landscape Program, Portrait Program, Action Program, or Shutter Priority exposure modes, then the ISO Speed submenu options will be grayed-out as soon as you exit the Exposure Mode submenu. Likewise, if you change the exposure mode from Landscape Program, Portrait Program, Action Program, or Shutter Priority to either Auto or Aperture Priority (Av) exposure mode, then the ISO Speed options will become available as soon as you exit the Exposure Mode submenu.

After you set the exposure mode to Aperture Priority (Av) or Shutter Priority (Tv) and exit the submenu, the live view of Capture mode will turn on automatically. You can then use the 4-way controller to adjust the aperture value (if in Av mode) or shutter speed (if in Tv mode) by pressing the up and down arrows (see below). If the camera cannot properly expose because the picture subject is out of range, as in very bright or very dark scenes, the text string (such as Av F5.6 1/1500) will turn red in the top overlay bar of live view. If you turn the image LCD off, the exposure mode will not change, but you will be unable to adjust the aperture value or shutter speed with the 4-way controller.

When you set the exposure mode to Aperture Priority (Av) and live view is on, pressing the up and down arrows on the 4-way controller will perform these specific functions:


- ◆ Up arrow – stops down the aperture (toward higher f-numbers)
- ◆ Down arrow – stops up the aperture (toward lower f-numbers)

When you set the exposure mode to Shutter Priority (Tv) and live view is on, pressing the up and down arrows on the 4-way controller will perform these specific functions:

- ◆ Up arrow – decreases toward shorter shutter speeds
- ◆ Down arrow – increases toward faster shutter speeds

**Note:** The option you set is active from shot-to-shot; it resets to its default setting when you cycle the power on the camera.

**Figure 34:** EV Compensation Submenu



**Table 13:** Exposure Mode Soft Keys

Soft Key	Function
Select	Places a checkmark by the highlighted setting, then returns to the Photo Assist menu.
Exit	Returns to the Photo Assist menu without changing the setting.

### EV Compensation Submenu

Use the EV (Exposure Value) Compensation submenu to manually adjust the exposure in 0.5 EV increments (- values for darker images, + values for lighter images). You can select from these options:

- ◆ -2.0
- ◆ -1.5
- ◆ -1.0
- ◆ -0.5
- ◆ 0 (Default)
- ◆ +0.5
- ◆ +1.0
- ◆ +1.5
- ◆ +2.0

**Table 14:** EV Compensation Soft Keys

Soft Key	Function
Default	Sets the exposure compensation to the default value.
Exit	Saves the setting and returns to the Photo Assist menu.

**Note:** The option you set is active from shot-to-shot; it resets to its default setting when you cycle the power on the camera.

**Figure 35:** White Balance Submenu



## White Balance Submenu

Use the White Balance submenu to correct the color applied to a captured image under different lighting conditions in order to make white areas in the image appear white without any color cast. You can select from these setting options:


- ◆ **Auto** (Default) – Use when you want the camera to automatically sense the lighting conditions and adjust the white balance appropriately for optimum color reproduction in the image.
- ◆ **Daylight** – Use when you are taking a picture in daylight without artificial lighting.
- ◆ **Tungsten** – Use when you are taking a picture under normal incandescent lighting, such as the light from tungsten filament light bulbs in household lamps.
- ◆ **Fluorescent** – Use when you are taking a picture under fluorescent lighting.

**Table 15:** White Balance Soft Keys

Soft Key	Function
Select	Places a checkmark by the selected setting, then returns to the Photo Assist menu.
Exit	Returns to the Photo Assist menu without changing the setting.

**Note:** The option you set is active from shot-to-shot; it resets to its default setting when you cycle the power on the camera.

**Figure 36:** Focus Mode Submenu



**Note:** Setting the camera to Manual focus mode cancels any selected auto focus range (Macro or Infinity) and turns off the corresponding icon on the status LCD.

## Focus Mode Submenu

Use the Focus Mode submenu to control how your camera focuses. You can select from these setting options:

- ◆ Auto Focus (Default)
- ◆ Manual Focus

After you set the focus mode to Manual Focus and exit the submenu, the live view of Capture mode will turn on automatically, and the focus distance will appear in the far left side of the top overlay bar. You can then adjust the focus distance by pressing the left and right arrows on the 4-way controller (see below). If you turn off the image LCD, Manual Focus will still be on, but you will no longer be able to adjust the focus distance with the 4-way controller.

When you set the focus mode to Manual Focus and live view is on, pressing the right and left arrows on the 4-way controller will perform these specific functions:


- ◆ Right arrow – increases focus distance
- ◆ Left arrow – decreases focus distance

**Table 16:** Focus Mode Soft Keys

Soft Key	Function
Select	Places a checkmark by the highlighted setting, then returns to the Photo Assist menu.
Exit	Returns to the Photo Assist menu without changing the setting.

**Note:** The option you set is active from shot-to-shot; it resets to its default setting when you cycle the power on the camera.

**Figure 37:** AE Metering Submenu



## AE Metering Submenu

Use the AE (Automatic Exposure) Metering submenu to select the area of the scene that the camera will use to set the exposure when you take a picture.

**Table 17:** AE Metering Submenu

Setting	Function
Average (default)	The camera uses the entire frame to calculate exposure.
Center-weighted	The camera uses the center half of the total pixels to calculate exposure.
Spot	The camera calculates exposure based only on a small region in the center of the scene.

**Table 18:** AE Metering Soft Keys

Soft Key	Function
Select	Places a checkmark by the highlighted setting, then returns to the Photo Assist menu.
Exit	Returns to the Photo Assist menu without changing the setting.

**Note:** The option you set is active from shot-to-shot; it resets to its default setting when you cycle the power on the camera.

**Figure 38:** ISO Speed Submenu



## ISO Speed Submenu

Use the ISO Speed submenu to set the ISO speed. Similar to film, slower ISO speeds require longer exposures, but produce higher quality images. In contrast, faster ISO speeds allow for shorter exposures, but produce noisier images. You can select from these setting options:

- ◆ Auto (Default) – The camera automatically determines the best ISO speed for the scene.
- ◆ 100
- ◆ 200


The ISO Speed submenu is only available for Auto and Aperture Priority exposure modes. When the exposure mode is set to Landscape Program, Portrait Program, Action Program, or Shutter Priority, the ISO Speed submenu is grayed-out and the ISO Speed is set to Auto.

**Table 19:** ISO Speed Soft Keys

Soft Key	Function
Select	Places a checkmark by the highlighted setting, then returns to the Photo Assist menu.
Exit	Returns to Photo Assist menu without changing the setting.

**Note:** An image stamp becomes permanently embedded in the image and overwrites data in the image. You *cannot* remove it later.

**Figure 39:** Image Stamp Menu



**Figure 40:** Date/Time Stamp Submenu



## Image Stamp Menu

Use the Image Stamp menu to place watermarks on your images as you capture them. The Image Stamp menu has these options:

- ◆ Date & Time
- ◆ Text
- ◆ Logo

**Table 20:** Image Stamp Soft Keys

Soft Key	Function
Edit	Opens submenu associated with the selected menu option.
Exit	Exits this menu and returns to the live view in Capture mode.

## Date/Time Stamp Submenu

Use the Date/Time Stamp submenu to stamp an image with the current date, time, both date and time, or neither.

You can set the following properties of the date/time stamp:

- ◆ Type
- ◆ Placement
- ◆ Transparency
- ◆ Text color
- ◆ Background

**Table 21: Settings for Date/Time, Text, and Logo Stamp Submenus**

Setting	Options
Type	None (default), Both, Date, Time
Placement	 Top right quadrant of image  Center of image  Bottom left quadrant of image  Bottom right quadrant of image  Top left quadrant of image
Transparency	Opaque - There will be a background box around the text. Semi - There will be a translucent background box. Clear - There will be no background behind the text.
Text Color	White, red, green, blue, cyan, magenta, yellow, black
Background	Black, white, red, green, blue, cyan, magenta, yellow

**Note:** If you have set the Color in the File Settings submenu to either B&W (black and white) or Sepia, the Image Stamp will also be B&W or Sepia, regardless of the color you set for the Text and Background Colors in the Image Stamp menu.

**Table 22: Date/Time Stamp Soft Keys**

Soft Key	Function
Default	Returns all settings on screen to their defaults
Exit	Saves the settings, exits this submenu, and returns to the Image Stamp menu.

**Figure 41:** Text Stamp Submenu



**Note:** Text strings can be a maximum of 31 characters.

## Text Stamp Submenu

Use the Text Stamp submenu to stamp an image with text that you enter using the text entry dialog.

Text Stamp is either On or Off, and the default is Off. When it is On, you can set the following properties of the text stamp:

- ◆ Placement
- ◆ Transparency
- ◆ Text color
- ◆ Background

**Table 23:** Text Stamp Soft Keys

Soft Key	Function
Edit	Opens text entry screen to enter the text stamp that will appear on the images. (Available only when the first line is set to On.)
Default	Returns all settings on screen to their defaults.
Exit	Exits this submenu and returns to the Image Stamp menu.

**Figure 42:** Logo Stamp Submenu



**Note:** By default, no logo files are included with your camera. To learn how to get logo files, see the HP website at: [www.hp.com/photosmart](http://www.hp.com/photosmart).

## Logo Stamp Submenu

Logo Stamp is either On or Off, and the default is Off. When it is On, you can:

- ◆ Stamp the image with a logo file
- ◆ Choose one logo from a list
- ◆ Choose the placement of the logo
- ◆ Choose the color
- ◆ Choose the transparency level

**Table 24:** Logo Stamp Soft Keys

Soft Key	Function
Edit	Opens the Logo Files dialog. (Available only when Logo Stamp is on.)
Default	Returns all settings on screen to their defaults.
Exit	Exits this submenu and returns to the Image Stamp menu.

## Logo Files Dialog


When you press the Edit soft key in the Logo Stamp submenu, the Logo Files dialog is displayed. Use the up and down arrows on the 4-way controller to select the file you want to use as the Logo Stamp from the list of available files.

**Table 25:** Logo Files Soft Keys

Soft Key	Function
Select	Places a checkmark next to the logo file, returns to the Logo Stamp submenu, and displays the selected file name in the second line of the submenu.
Exit	Exits this dialog and returns to Logo Stamp submenu.

**Note:** All options you set in the Preferences menu are active from shot-to-shot; they also remain set when you cycle the power on the camera.

**Figure 43:** Preferences Menu



**Note:** For more information on using the Preferences menu to set up your camera, see “Appendix A: Using the Preferences Menu” starting on page 94.

## Preferences Menu

Use the Preferences menu to change a variety of your camera’s general settings. You can select from these options:

- ◆ Display
- ◆ Sound
- ◆ Format Card
- ◆ PC Connect Mode
- ◆ Date & Time
- ◆ Image Counter
- ◆ Camera Name
- ◆ Language
- ◆ Reset Settings

**Table 26:** Preferences Soft Keys

Soft Key	Function
Edit	Opens submenu associated with the highlighted menu option.
Format	Available only when Format Card is highlighted.
Reset	Available only when Reset Settings is highlighted.
Exit	Exits this submenu and returns camera to Capture mode.

**Figure 44:** Display Submenu



**Note:** The Instant Review setting determines the amount of time an Instant Review of an image you just captured is displayed on the image LCD. See “Using Instant Review” on page 25 for more information.

The Live View setting determines whether the live view of Capture mode will automatically display on the image LCD or not when you power on the camera and set the camera to Capture mode.

The Sleep Timeout setting determines how quickly the camera goes into sleep mode and turns off the image LCD when you are not using the camera.

## Display Submenu

Use the Display submenu to control the display on the camera’s image LCD.


**Table 27:** Display Submenu

Setting	Default	Options
Brightness Level	4	1 (dimkest) - 7 (brightest)
Instant Review (see Note)	3 sec	1-10 sec 15 sec 20 sec 25 sec 30 sec Off
Live View (see Note)	Off	On / Off
Sleep Timeout (see Note)	2 min	30 sec 1 min 2 min 5 min

**Table 28:** Display Soft Keys

Soft Key	Function
Default	Returns all settings to their defaults.
Exit	Saves the settings, exits this submenu, and returns to the Preferences menu.

**Figure 45:** Sound Submenu



**Note:** The System Sounds setting determines whether or not you will hear the camera's system sounds, such as shutter clicks, beeps, and so forth.

**Figure 46:** Format Card Confirmation Screen



## Sound Submenu

Use the Sound submenu to control the sounds used on your camera.

**Table 29:** Sound Submenu

Setting	Default	Options
Volume Level	7	1 (lowest) - 7 (highest)
System Sounds (see Note)	On	On / Off

**Table 30:** Sound Soft Keys

Soft Key	Function
Default	Returns all settings to their defaults.
Exit	Saves the settings, exits this submenu, and returns to the Preferences menu.

## Format Card Option

Use the Format Card option to reformat the memory card. Reformatting will erase all of the files on the card, including all images, protected files, folders, scripts, and so forth. You will see a confirmation of your choice to format the memory card (see Figure 46).

**Table 31:** Format Card Soft Keys

Soft Key	Function
Format	Reformats the memory card.
Cancel	Exits the confirmation screen and returns to the Preferences menu.

**Figure 47:** PC Connect Mode Submenu



**Note:** For more information on using the PC Connect Mode settings, see “Transferring Images to Your Computer” on page 38.

## PC Connect Mode Submenu

Use the PC Connect Mode submenu to specify how the camera will appear to your computer when connected via the USB interface in PC Connect mode. You can then transfer images from your camera to the computer via the USB interface.


**Table 32:** PC Connect Mode Submenu

Setting	Function
USB Disk Drive	The camera is operated as a USB Mass Storage Device and appears as a disk drive connected to the computer. You can copy images from your camera to the computer as you would from another disk drive. Use this setting to connect the camera to a Mac OS 8.6 or better computer, or to a Windows Me, 98, or 2000 computer.
Digita Device (default)	You can use software included with your computer or camera to transfer images to the computer. Use this setting to connect the camera to a Windows Me, 98, or 2000 computer.

**Table 33:** PC Connect Mode Soft Keys

Soft Key	Function
Select	Places a checkmark next to the selected item and returns to the Preferences menu.
Default	Resets the settings to their defaults.
Exit	Exits this submenu without changing the settings and returns to the Preferences menu.

**Figure 48:** Set Date & Time Submenu



**Figure 49:** Format Dialog



## Set Date & Time Submenu

Use the Set Date & Time submenu to set the camera's date and time. Press the up and down arrows on the 4-way controller to scroll through the list of numbers. Press the left and right arrows to move between the date/time fields.

**Table 34:** Set Date & Time Soft Keys

Soft Key	Function
Format	Opens the Format List dialog where you can select the format.
Exit	Saves the date and time settings, exits this submenu, and returns to the Preferences menu.

## Format Dialog

When you press the Format soft key in the Set Date & Time submenu, you see the Format dialog, which allows you to select from a list of six, predefined date and time formats.

**Table 35:** Format Soft Keys

Soft Key	Function
Select	Places a checkmark next to the selected format and returns to the Set Date & Time submenu.
Exit	Exits this dialog and returns to the Set Date & Time submenu.

**Figure 50:** Image Counter Submenu



**Note:** Once you have changed the Image Counter setting, you must power the camera off and then on again for the new setting to take effect.

## Image Counter Submenu

Use the Image Counter submenu to set how the image counter works.


**Table 36:** Image Counter Submenu

Setting	Function
Reset When Empty	Each time you delete all of the images on your camera, the counter restarts the first image captured at number 1.
Continuous Counter (default)	The images are counted according to the history of the camera's use. For example: image #400 is the 400th image to be captured with this camera.

**Table 37:** Image Counter Soft Keys

Soft Key	Function
Select	Places a checkmark next to the selected setting and returns to the Preferences menu.
Exit	Returns to the Preferences menu without changing the setting.

**Figure 51:** Camera Name Submenu



**Note:** Words wrap to the next line when they get too long.

## Camera Name Submenu

Use the Camera Name submenu to enter a unique name for your camera.

Press the left (Character Set Icon) soft key to toggle through the four character sets (capital letters, lowercase letters, numbers, and symbols) until you see the character set you want to use displayed in the left soft key label area on the overlay bar. Then press the:

- ◆ Up or down arrow on the 4-way controller to scroll through the list of characters.
- ◆ Right arrow on the 4-way controller to enter the selected character and advance the insertion point in the center of the screen.
- ◆ Left arrow on the 4-way controller to back up and delete a character.
- ◆ Middle (Space) soft key to create a space between words in the camera name.

**Table 38:** Camera Name Soft Keys

Soft Key	Function
Character Set Icon	Toggles through four character sets: capital letters, lowercase letters, numbers, and symbols.
Space	Adds a space, instead of a letter, and advances the insertion point. (The Space key does not appear if a space is not a valid character.)
Exit	Saves the text entered and returns to the Preferences menu.

**Figure 52:** Language Submenu



**Figure 53:** Reset Settings Confirmation Screen



## Language Submenu

English is set as the default language that is used on the camera. Use the Language submenu to select a language from the list of installed languages.

**Table 39:** Language Soft Keys

Soft Key	Function
Select	Places a checkmark next to the highlighted language and returns to the Preferences menu. The selected language is now used.
Exit	Returns to the Preferences menu without changing the setting.

## Reset Settings Option

Use the Reset Settings option to reset all of the camera settings (except for the Language, Format for the Set Date & Time, PC Connect Mode, and Video Preferences settings) to their defaults in one step. You will see a confirmation of your choice to reset the camera settings (see Figure 53).

**Table 40:** Reset Settings Soft Keys

Soft Key	Function
Reset	Resets all camera settings to their defaults and returns to the Preferences menu.
Cancel	Returns to the Preferences menu without changing the settings.

## Playback Mode Menu and Soft Keys

To access the Playback mode menu and related soft keys, turn the camera mode dial to Playback mode  and press the MENU button on the back of the camera. Once you have captured images, you can choose options and settings for the images within the one menu (Play Settings) of Playback mode.

### Play Settings Menu

There are three options in this menu:

- ◆ Slideshow
- ◆ Playback Rate
- ◆ Video


**Figure 54:** Play Settings Menu



**Table 41:** Play Settings Soft Keys

Soft Key	Function
Edit	Displays submenu for the highlighted option.
Exit	Exits this menu and returns to the Playback mode screen.

**Figure 55:** Slideshow Submenu



## Slideshow Submenu

Use the Slideshow submenu to select the criteria for a slideshow to be viewed “on the fly.”


**Table 42:** Slideshow Submenu

Setting	Default	Options
Content	All	All, Category
Duration	2 sec	1-10 sec
Sound	On	On, Off
Loop	On	On, Off

**Table 43:** Slideshow Soft Keys

Soft Key	Function
Start	Exits this submenu and displays the slideshow.
Cancel	Exits this submenu without changing the settings and returns to the Play Settings menu.
Exit	Sets all the settings, exits this submenu, and returns to the Play Settings menu.

**Figure 56:** Playback Rate Submenu



## Playback Rate Submenu

Use the Playback Rate submenu to establish a default playback rate for each image type.

**Table 44:** Playback Rate Submenu

Setting	Default	Options
Timelapse	3 sec	1-10 sec rate
Group	3 sec	1-10 sec rate

**Table 45:** Playback Rate Soft Keys

Soft Key	Function
Default	Returns all settings to their defaults.
Cancel	Exits this submenu without changing the settings and returns to the Play Settings menu.
Exit	Sets all the settings, then exits this submenu, and returns to the Play Settings menu.

**Figure 57:** Video Preferences Submenu



## Video Preferences Submenu

Use the Video Preferences submenu to specify the video format: NTSC or PAL. The format that you choose (NTSC or PAL) depends on your television's video input format:

- ◆ NTSC is the video connection standard used in the United States and Japan.
- ◆ PAL is the video connection standard used in Europe.

**Table 46:** Video Preferences Submenu

Setting	Default	Options
Video Out	NTSC	NTSC, PAL

**Table 47:** Video Preferences Soft Keys

Soft Key	Function
Cancel	Exits this submenu without changing the settings and returns to the Play Settings menu.
Exit	Saves the setting, exits this submenu, and returns to the Play Settings menu.

## Review Mode Menus and Soft Keys

To access the Review mode menus and related soft keys, turn the camera mode dial to Review mode  and press the MENU button on the camera. Once you have captured images, you can change specifications for the images within the four Review mode menus:

- ◆ “Edit Menu” on page 78
- ◆ “Print Order Form Menu” on page 81
- ◆ “Transmit Menu” on page 84
- ◆ “Find Menu” on page 86

### Edit Menu

Use the Edit menu to perform the following actions on selected images:

- ◆ Delete
- ◆ Group
- ◆ Protect
- ◆ Categorize

Figure 58: Edit Menu



Figure 59: Delete Confirmation Screen



### Delete Option

Use the Delete option to delete the current image, a group of images, or all of the marked images from the memory card. Note that protected images within a group marked for deletion will not be deleted until you unprotect them. You will see a confirmation of your choice to delete the images (see Figure 59).

Table 48: Delete Soft Keys


Soft Key	Function
Delete	Deletes the selected image(s) and then returns to the Review mode screen.
Cancel	Exits and returns to the Review mode screen without deleting image(s).

**Note:** A group becomes a folder on the memory card, in which all the images in that group are stored.

**Figure 60:** Group Name Submenu



**Figure 61:** Protect Option



## Group Name Submenu

Use the Group Name submenu to group all of the images that you have marked. You can start a group, add images to an existing group, or move images from one group to a new group. Note that you can use the Dissolve soft key to dissolve groups.

**Table 49:** Group Name Soft Keys

Soft Key	Function
Add (If current image is not grouped, but at least one group exists.)	Displays a dialog that allows you to create a new group or add to an existing group. (Images are moved into groups, not replicated.)
Create (If current image is not grouped and no groups exist.)	
Dissolve	Removes any grouping previously applied.
Exit	Exits and returns to the Review mode screen.

## Protect Option

Use the Protect option to protect or unprotect marked images. When an image is protected, you can't delete it. If there are no marked images, then the Protect command protects the currently selected image. If the marked or selected single image is unprotected, only the Protect soft key appears. If the image is protected, only the Unprotect soft key appears. If multiple images, both protected and unprotected, are marked, then both the Protect and Unprotect soft keys appear.

Once you have protected an image, the following restrictions apply to the image file:

- ◆ You cannot delete the image nor an attached sound.
- ◆ You cannot attach or re-record a sound.
- ◆ You cannot attach, change, or remove a category.
- ◆ Deleting a group will delete only the unprotected images within that group.
- ◆ You cannot change the file name.
- ◆ You can move the image file into and out of groups.
- ◆ The image file will be marked "Read Only" in Windows when transferred to a PC.

**Note:** A category is an image tag which is useful for finding images or playing a slideshow of a category of images.

**Figure 62:** Categories Submenu



**Table 50:** Protect Soft Keys

Soft Key	Function
Protect	Appears if selected images are unprotected. Allows you to protect the current image.
Unprotect	If multiple images are marked, this soft key appears along with the Protect soft key. Allows you to unprotect images.
Exit	Cancels the protect operation and returns to the Review mode screen.

### Categories Submenu

Use the Categories submenu to assign images to a category. The camera has predefined categories, such as vacation, work, pets, family, and friends

Choose the category you want using the 4-way controller, then use the Select soft key to attach the category to the image. You can assign categories to one image at a time, or you can categorize all marked images at once.


**Table 51:** Categories Soft Keys

Soft Key	Function
Select	Assigns a category to an image or marked images. Places a checkmark next to the assigned category.
Exit	Updates the image files with the new categories and returns to the Review mode screen.

## Print Order Form Menu

Use the Print Order Form menu to create a Digital Print Order Format (DPOF) file.

**Figure 63:** Print Order Form Menu



**Note:** See “Using a Digital Print Order Format (DPOF) File” on page 44 for more information.


**Table 52:** Print Order Form Menu

Option	Function
Add Images	Allows you to add current image or marked images to the DPOF file. Opens a secondary screen to specify number of copies and size of photos.
View Order	Displays a scrolling list of the contents of the DPOF file.
Erase Order	Erases the contents of your DPOF file.

**Table 53:** Print Order Form Soft Keys

Soft Key	Function
Add/Select	Opens appropriate submenu.
Erase	Asks for confirmation to delete all entries of the DPOF file.
Exit	Exits and returns to the Review mode screen.

**Figure 64:** Add to Order Submenu



**Note:** Standard means one of the standard print sizes. You specify the exact size you want your Standard prints to be at the printer. For example, you can specify that all Standard images be printed at 4" x 6".

## Add to Order Submenu

Use the Add to Order submenu to add current or marked images to the DPOF file and to set up the print settings for those images.

If you have any marked images, they are added to the order. If no images are marked, the image currently selected in the Review mode is added to the order.


**Table 54:** Add to Order Submenu

Setting	Options
Copies	1-999 (1=default)
Size	Index - Thumbnails Standard (default) - One of the standard print sizes (see Note)


**Table 55:** Add to Order Soft Keys

Soft Key	Function
Add	Adds images to the DPOF file.
Cancel	Exits without adding images.

**Figure 65:** Print Order Form Screen of the View Order Option



**Figure 66:** Erase Order Confirmation Screen



## View Order Option

Use the View Order option to view a list of ordered images in the DPOF file. You can scroll through this list using the up and down arrows on the 4-way controller. However, you cannot edit this list.

**Table 56:** View Order Option Soft Key

Soft Key	Function
Exit	Returns to the Print Order Form menu.


## Erase Order Option

Use the Erase Order option to erase all of the entries from the DPOF file. You will see a confirmation of your choice to erase all entries (see Figure 66).

**Table 57:** Erase Order Soft Keys

Soft Key	Function
Erase	Erases the contents of the DPOF file.
Exit	Returns to the Print Order Form menu without clearing the DPOF file.

**Figure 67:** Transmit Menu



**Note:** For more information, see “Transmitting Images Between Two Cameras” on page 48.

## Transmit Menu

Use the Transmit menu to transfer images in one of two ways:

- ◆ Camera-Camera
- ◆ Camera-Printer

### Camera-Camera Option

Use the Camera-Camera option to send current or marked images to, or receive images from, another Digita camera.

**Table 58:** Camera-Camera Soft Keys

Soft Key	Function
Send	Sets the camera into sender mode. Displays a screen to confirm sending images to another camera and then returns to the Review mode screen.
Receive	Sets the camera to receiver mode. Brings up a screen to confirm receiving images from another camera and returns to the Review mode screen.
Stop	Stops transmitting and returns to the Transmit menu.
Exit	Exits this screen and returns to the Review mode screen.

**Note:** For more information, see “JetSending Images to a Printer” on page 46.


### Camera-Printer Option

Use the Camera-Printer option to send current or marked images to a printer via the HP JetSend infrared technology.

**Table 59: Camera-Printer Soft Keys**

Soft Key	Function
Send	Sets the camera to sender mode. Displays a screen to confirm sending images and then returns to the Review mode screen.
Exit	Exits this screen and returns to the Review mode screen.

**Figure 68:** Find Menu



## Find Menu

Use the Find menu to search for specific images, either by category or by date (but not both at the same time). When you return to the Review mode to view the results of the find operation, the Find icon will appear in the lower, right corner. All find results will be chronologically displayed. If no images match your search criteria, then you will see an error message.

**Table 60:** Find By Date and Find By Category Soft Keys

Soft Key	Function
Edit	Displays specific find options (Find By Date, or Find By Category).
Select	Selects the category to find.
Exit	Exits the Find screen and returns to the Review mode screen.
Mark	After the Find operation, marks a selected image.
Show All	After the Find operation, returns the thumbnail row to the original, chronological list of images and turns off the Find icon.

**Figure 69:** Find By Date Submenu



**Figure 70:** Find By Category Submenu



## Find By Date Submenu

Use the Find By Date submenu to enter the range of dates using the 4-way controller.

**Table 61:** Find By Date Soft Keys

Soft Key	Function
Find	Executes the Find criteria and returns to the Review mode screen to display results.
Exit	Exits this screen and returns to the Find menu without executing the Find command.

## Find By Category Submenu

Use the Find By Category submenu to scroll through the list of categories and enter the “find” category with the 4-way controller. You can then use the Select soft key to select the category with which you want to do the search.

**Table 62:** Find By Category Soft Keys

Soft Key	Function
Select	Selects the checkmarked category from the Find By Category list and executes the Find command.
Exit	Exits this screen and returns to the Find menu without executing the Find command.

**Note:** For information about preserving battery life and about HP accessories you can use to power the camera (such as the HP AC power adapter, and the HP rechargeable batteries and battery recharger), see Appendix B starting on page 103.

## Overview

This chapter explains how to troubleshoot some common problems you may encounter while using your camera.

If you still cannot remedy the problem, contact HP for help. See “Contacting HP Customer Care” on page 93.

## Troubleshooting Common Problems

Problem	Solution
The camera will not power on	<ul style="list-style-type: none"><li>◆ If you are using batteries:<ul style="list-style-type: none"><li>◆ Check the type of batteries that you have installed in the camera. They may not be the appropriate type for a digital camera. Use only high quality AA photo lithium, high drain alkaline, or NiMH batteries.</li><li>◆ Check to make sure the batteries are inserted correctly. The positive and negative poles may be reversed.</li><li>◆ The batteries' charge may be low or completely drained. Try installing new batteries or recharged batteries,</li></ul></li><li>◆ If you are using the HP AC power adapter instead of batteries:<ul style="list-style-type: none"><li>◆ Is the AC power adapter plugged in?</li><li>◆ Is there power at the outlet?</li><li>◆ Is the AC power adapter dead?</li></ul></li><li>◆ Also see the next problem and solution, below.</li></ul>
The camera is not responding at all – it won't power on or off	Open the battery compartment door, remove the batteries and/or unplug the HP AC power adapter, and let the camera sit for about 20 minutes with the battery door open to allow the camera to discharge fully. Then either re-install the batteries or plug in the AC power adapter, close the battery door, and try powering on the camera again.
The camera is powered on, but there's no display on the image LCD	<ul style="list-style-type: none"><li>◆ Press the DISPLAY button again.</li><li>◆ Power the camera off and then on again.</li><li>◆ The batteries may be nearly drained. (If so, you should see an empty battery status icon on the status LCD.) Leave the image LCD turned off, or insert charged batteries.</li></ul>

## Problem

## Solution

The camera is powered on, but when I press a button, the camera does not respond

- ◆ Try powering the camera off and then on again.
- ◆ Remove the batteries or unplug the HP AC power adapter. Then reinstall the batteries or plug in the AC power adapter, and power on the camera again.

I always have to re-set the date and time after I change the batteries in the camera or unplug the HP AC power adapter from the camera

This will happen if either you remove the batteries from the camera, or you remove the batteries and unplug the HP AC power adapter, for more than 5 minutes. (Note that even if the batteries are drained, the date and time will remain set as long as you leave the drained batteries in the camera.)

When changing batteries, try to put the new batteries in within 5 minutes of when you remove the old batteries. Similarly, if you are using the HP AC power adapter, either leave batteries in the camera (even if the batteries are drained) when you unplug the adapter, or unplug the adapter for less than 5 minutes at a time.

The rechargeable HP NiMH batteries I'm using don't seem to power the camera for very long

You must recharge all 4 HP NiMH batteries after fully draining them four times for the batteries to reach their optimum capacity and performance. For more information, see "Using the HP NiMH Batteries and Recharger" on page 108.

The incorrect language is set on the camera

1. Set the camera mode dial to Capture mode .
2. Power on the camera if you haven't already.
3. Press the MENU button to display the Capture mode menus on the image LCD.
4. Press the right arrow on the 4-way controller *three* times to move to the Preferences menu.
5. Press the down arrow on the 4-way controller *seven* times to move to the Language menu option.
6. Press the left (Edit) soft key. The Language submenu is displayed.
7. Press the down or up arrow on the 4-way controller to highlight the language you want.
8. Press the left (Select) soft key to select the highlighted language and to exit this screen. You return to the Preferences menu of Capture mode, and the camera is now using the language you set.
9. Press the right (Exit) soft key to exit the menu.

## Problem

## Solution

The camera is displaying an error message

There are 3 different types of error messages you may see on the camera:

- ◆ Memory card is not formatted - “Err” is displayed on the status LCD and the message “Card requires formatting” is displayed on the image LCD. This means the memory card needs to be formatted. Either see “Formatting the Memory Card” on page 98 for information on how to format the card, or replace the current memory card with another, formatted one.
- ◆ Flash cannot charge - “Err” and the lightning bolt icon blinks on the status LCD for 3 seconds, then the camera powers off. “Err” and the lightning bolt will remain displayed on the status LCD until the batteries are drained. This problem requires repair of the camera. See “Contacting HP Customer Care” on page 93 to call HP for help.
- ◆ Other errors - The camera locks up and blinks a 3-digit error code on the status LCD. Try powering the camera off and then on again. You may also need to remove the batteries and install them again. If the problem persists, see “Contacting HP Customer Care” on page 93 to call HP for help. Be sure to tell the HP representative the error code that you see displayed on the status LCD.

The camera’s status LCD is flashing 000

There is no memory card installed in the camera, or the memory card is full. If there isn’t one installed, power off the camera, install a memory card in it, and then power on the camera again. If the memory card is full, transfer the images you want to keep to your computer (see “Transferring Images to Your Computer” on page 38), and then delete images from the memory card to free-up space.

The image counter on the camera’s status LCD won’t reset when the memory card is empty

The default setting for the image counter is continuous counting of images. If you want to have it reset to zero when the memory card is empty, you can change the setting in the Image Counter submenu (under the Preferences menu in Capture mode). See “Image Counter Submenu” on page 71. Once you have changed the image counter setting, you must power the camera off and then on again. Also ensure that the camera’s memory card is completely empty.

The camera will not focus

- ◆ Ensure that the camera mode dial is set to Capture mode .
- ◆ You may be too close to the subject. Try using the Macro auto focus range.
- ◆ Try using Focus Lock. See “Using Focus Lock” on page 18.

Digital zoom is not working

For digital zoom to work correctly, the camera’s image LCD must be turned on. Ensure that the camera mode dial is set to Capture mode . Then press the DISPLAY button.

## Problem

## Solution

The HP Remote Control is not working

- ◆ The HP Remote Control does not work while the flash is charging. Try pressing the Remote Control's trigger again once the flash has charged.
- ◆ The HP Remote Control may not work if the camera is sitting under bright lights or in full sun. In this case, use the 10-Second Timer mode, instead. (See "Setting the Timer Mode" on page 11.)
- ◆ The battery in the HP Remote Control may be dead. If so, replace the battery.

The captured images are over- or under-exposed

Change the exposure compensation setting in the EV Compensation submenu of the Photo Assist menu. See "EV Compensation Submenu" on page 57.

The computer does not recognize the camera when connected via the USB cable

On both Windows and Macintosh computers:

- ◆ Is the camera powered on?
- ◆ Is the camera mode dial set to PC Connect mode **PC**?
- ◆ Is the USB cable firmly attached to both the camera and computer?
- ◆ Is the USB port enabled on the computer?
- ◆ Are you using a USB hub? If so, you may need to reset the hub. (It may have become disabled due to an electrical disturbance such as that generated by static electricity.) To reset the USB hub, leave the camera connected to the hub, disconnect the hub from the computer, and remove power from the hub. Then reconnect the power to the USB hub and reconnect the hub to the computer.
- ◆ Try powering the camera off and then on again.

On Windows Me, 98, and 2000 computers:

- ◆ If you are using the Microsoft Scanner and Camera Wizard (for Windows Me) or the HP Photo Imaging Software (for Windows 98 and 2000) to transfer images, is the PC Connect Mode submenu setting (under the Preferences menu of Capture mode) in the camera set to Digital Device?
- ◆ If you are using the PC Connect Mode submenu setting of USB Disk Drive in the camera instead, does the camera appear as a disk drive in Windows Explorer?

Note: Computers running Windows NT 4.0 cannot connect to the camera via the USB cable, because Windows NT 4.0 does not support the USB interface. You must use either an HP P1000/1100 or similar printer, or a memory card reader to transfer the images to your Windows NT 4.0 computer, instead.

On Macintosh computers:

- ◆ Is the PC Connect Mode submenu setting (under the Preferences menu of Capture mode) in the camera set to USB Disk Drive?

## Problem

## Solution

A TWAIN error occurs when a software program tries to acquire an image from the camera

- ◆ Verify that the software program can see the camera through its own TWAIN select source. While software programs vary on how to select a TWAIN source, generally the easiest way to determine whether a program supports TWAIN is to see if there is an Acquire selection in the File menu. If not, then check for a TWAIN command located under the Import selection of the File menu. If neither exists, and you have a scanner, check the manual for the software program to see if you can use TWAIN to scan images, instead.
- ◆ For more detailed information about this problem, consult the Technical Support section for this camera that is located on the HP website at: [www.hp.com/photosmart](http://www.hp.com/photosmart).

I am trying to name a group of images, but the camera is not responding

- ◆ Try using a different group name. Note that the camera does not accept group names that begin with BR or TL (regardless of language).
- ◆ Group names must be eight characters or less, and cannot contain spaces.

I am searching through images by date, and have selected the find dates, but the camera is not responding

Make sure that the From date is prior or equal to the To date.

I can't get images to display on my television when I connect my camera to it

Make sure that the video output format (NTSC or PAL) that you set in the Video Preferences submenu of Playback mode is correct for the video input format of your television. (See "Video Preferences Submenu" on page 77.)

I'm having trouble JetSending an image to my printer

- ◆ Be aware that it will take an average of 20 seconds to transfer an image from the camera to a printer via JetSend.
- ◆ Make sure that your printer is JetSend-capable.
- ◆ Make sure that the camera's infrared window is lined-up with the printer's infrared sensor, and that the camera and printer are about 10 inches apart.

I'm having trouble sending images to another camera

- ◆ Make sure that the other camera is a Digital camera.
- ◆ Make sure that the camera's infrared window is lined-up with the other camera's infrared sensor, and that the cameras are about 10 inches apart.



**Note:** For a *complete* list of HP's Customer Support Centers worldwide, go to the HP website, [www.hp.com/photosmart](http://www.hp.com/photosmart), and click the **Assistance** button on the navigation bar.

## Contacting HP Customer Care

### HP Customer Care Online

Click your way to a great solution! The HP website, [www.hp.com/photosmart](http://www.hp.com/photosmart), is a great place to start for answers to questions about your HP products. You'll get instant access to helpful tips and tricks, downloadable drivers, and the latest product and software updates – 24 hours a day, 7 days a week.

### HP Customer Care by Phone

If you encounter a problem with your camera that is not covered in this chapter, contact HP for help. HP has Customer Support Centers worldwide, some of which are listed below.


#### HP's Customer Support Centers

Replace a + with your international telephone access code.

North America	Canada: 905-206-4663 Mexico - Mexico City: +52 58 9922 Mexico - Outside Mexico City: +01 800 472 6684 United States: 208-376-3686
Europe	Belgium - Dutch: +32 (0)2 626 8806 Belgium - French: +32 (0)2 626 8807 Denmark: +45 39 29 4099 Finland: +358 (0)203 47 288 France: +33 (0)1 43 62 34 34 Germany (24PF/min): +49 (0)180 52 58 143 Italy: +39 02 264 10350 Netherlands: +31 (0)20 606 8751 Norway: +47 22 11 6299 Spain: +34 902 321 123 Sweden: +46 (0)8 619 2170 United Kingdom: +44 (0)207 512 52 02 English language support from other European countries: +44 (0)171 512 52 02
Asia/Pacific	Australia: +61 3 8877 8000 Korea: +82 (2) 3270 0700 Singapore: +65 272 5300 Taiwan: +886 (2) 2717 0055

**Note:** For reference information regarding the options and soft keys in the Preferences menu, see “Preferences Menu” starting on page 66.

**Figure 71:** Preferences Menu



**Note:** All of the settings you make in the Preferences menu are active from shot-to-shot; they also remain set when you cycle the power on the camera.

### Overview

Use the Preferences menu in Capture mode to change a variety of your camera's general settings. For example, with the Preferences menu options you can change the brightness of the camera's image LCD or the volume of the camera's sounds, reformat the memory card in the camera, change the date and time on the camera, or set the mode for connecting the camera to a computer.

This appendix covers the following topics:

- ◆ “Accessing the Preferences Menu” on page 94
- ◆ “Setting the Display” on page 95
- ◆ “Controlling Camera Sounds” on page 97
- ◆ “Formatting the Memory Card” on page 98
- ◆ “Selecting the PC Connect Mode” on page 98
- ◆ “Setting the Date and Time” on page 99
- ◆ “Setting the Image Counter” on page 100
- ◆ “Naming Your Camera” on page 101
- ◆ “Selecting a Language” on page 102
- ◆ “Resetting Camera Settings” on page 102

### Accessing the Preferences Menu

To access the Preferences menu:

- 1 Set the camera mode dial to Capture mode .
- 2 Power on the camera if you haven't already.
- 3 Press the MENU button on the back of the camera. The Capture mode menus are displayed on the image LCD.
- 4 Press the right arrow on the 4-way controller *three* times to move to the Preferences menu (see Figure 71).
- 5 Press the down arrow on the 4-way controller to move the highlight to the menu option you want to select.
- 6 Press the left (Edit, Format, or Reset) soft key to select the highlighted menu option.

**Figure 72:** Display Submenu



## Setting the Display

Use the Display submenu to control the display on the camera's image LCD.

### Brightness Level

Use the Brightness Level setting to control the brightness of the display on the camera's image LCD. You can set the Brightness Level from 1 (dimkest) to 7 (brightest). The default value is 4.

To change the Brightness Level:

- 1 Press the down or up arrow on the 4-way controller, if needed, to highlight the Brightness Level option.
- 2 Press the right or left arrow on the 4-way controller to scroll through the values until you see the value you want.
- 3 Press the right (Exit) soft key to save the setting, exit the Display submenu, and return to the Preferences menu.

### Instant Review

The camera's Instant Review feature allows you to see displayed on the image LCD either the One Shot image, the final image of a Continuous image sequence, or the first image of a Timelapse sequence you just captured. (See "Using Instant Review" on page 25 for more information.) The default setting is that Instant Review is on for 3 seconds, and the maximum setting is that it is on for 30 seconds, after you capture either a One Shot image or the final image in a Continuous or Timelapse sequence.

To change the duration of the Instant Review period, or to turn Instant Review Off:

- 1 Press the down or up arrow on the 4-way controller to highlight the Instant Review option.
- 2 Press the right or left arrow on the 4-way controller to scroll through the values until you see the value you want.
- 3 Press the right (Exit) soft key to save the setting, exit the Display submenu, and return to the Preferences menu.

**Note:** The image LCD uses a lot of battery power. If you are running your camera on batteries rather than with the HP-approved AC power adapter, you may want to limit your use of the image LCD. In turn, you may want to leave the Live View setting at its default Off value to preserve battery power.

**Note:** For convenience as you learn to use your camera's features and menu options, you may want to set the Sleep Timeout to the longest interval (5 minutes). This will give you time to consider a feature or menu option before the camera goes into sleep mode and the image LCD turns off.

## Live View

The Live View setting determines whether the live view of Capture Mode will automatically display on the image LCD or not when you power on the camera and set the camera to Capture mode. The default value for Live View is Off.

To change the setting so Live View is On (that it will always display on the image LCD when you power on the camera and set the camera to Capture mode):

- 1 Press the down or up arrow on the 4-way controller to highlight the Live View option.
- 2 Press the right or left arrow on the 4-way controller to change the value to On.
- 3 Press the right (Exit) soft key to save the setting, exit the Display submenu, and return to the Preferences menu.

## Sleep Timeout

Prior to the camera completely powering itself off due to inactivity, the camera goes to “sleep” by turning off the image LCD and either turning off or slowing down other functions to conserve power. Pressing any button on the camera (except the power switch) “wakes” the camera from sleep mode.


After the camera goes to sleep, it will power off after an additional 5 minutes of inactivity. Once the camera completely powers itself off, you must use the power switch to power it on again.

The Sleep Timeout setting determines how quickly the camera goes into sleep mode when you are not using the camera. The default value is 2 minutes.

To change the Sleep Timeout:

- 1 Press the down or up arrow on the 4-way controller to highlight the Sleep Timeout option.
- 2 Press the right or left arrow on the 4-way controller to scroll through the values until you see the value you want.
- 3 Press the right (Exit) soft key to save the setting, exit the Display submenu, and return to the Preferences menu.

**Figure 73:** Sound Submenu



## Controlling Camera Sounds

Use the Sound submenu to control the sounds used on your camera

### Volume Level

The Volume Level setting allows you to determine the volume level of the sounds on your camera. This includes both the system sounds (see the next subsection) and the sounds you attach to images via the Sound Record button (see “Recording Sound” on page 26). You can set the Volume Level from 1 (lowest/softest) to 7 (highest/loudest). The default value is 4.

To change the Volume Level:

- 1 Press the down or up arrow on the 4-way controller, if needed, to highlight the Volume Level option.
- 2 Press the right or left arrow on the 4-way controller to scroll through the values until you see the value you want.
- 3 Press the right (Exit) soft key to save the setting, exit the Sound submenu, and return to the Preferences menu.

### System Sounds

The Systems Sounds setting determines whether or not you will hear the camera’s system sounds, such as shutter clicks, beeps, and so forth. The default value is On (that you will hear system sounds).

To change the setting so that System Sounds are turned Off:

- 1 Press the down or up arrow on the 4-way controller to highlight the System Sounds option.
- 2 Press the right or left arrow on the 4-way controller to change the value to Off.
- 3 Press the right (Exit) soft key to save the setting, exit the Sound submenu, and return to the Preferences menu.

Figure 74: Format Card Confirmation Screen



Figure 75: PC Connect Mode Submenu



**Note:** The USB Disk Drive mode will remain set on your camera only if you power off the camera by using the power switch. By powering off the camera correctly, you will *not* have to repeat these procedures when transferring images to your computer in the future.

## Formatting the Memory Card

Use the Format Card option to reformat the memory card in your camera. Reformatting will erase all of the files (images) on the memory card, including protected files, folders, scripts, and so forth.

When you select the Format Card option by pressing the left (Format) soft key, you will see a confirmation of your choice to format the memory card (see Figure 74). You can either press the middle (Format) soft key to reformat the memory card, or press the right (Cancel) soft key to exit the confirmation screen without reformatting the memory card and return to the Preferences menu.

## Selecting the PC Connect Mode

Use the PC Connect Mode submenu to specify how the camera will appear to your computer when connected via the USB interface in PC Connect mode. You can then transfer images from your camera to the computer via the USB interface. Table 63 explains the PC Connect Mode settings and their functions. The currently selected mode is indicated by the checkmark to the left of it. The default mode is Digita Device.


Table 63: PC Connect Mode Submenu

Setting	Function
USB Disk Drive	The camera is operated as a USB Mass Storage Device and appears as a disk drive connected to the computer. You can copy images from your camera to the computer as you would from another disk drive. Use this setting to connect the camera to a Mac OS 8.6 or better computer, or to a Windows Me, 98, or 2000 computer.
Digita Device (default)	You can use software included with your computer or camera to transfer images to the computer. Use this setting to connect the camera to a Windows Me, 98, or 2000 computer.

To change the PC Connect Mode:

- 1 Press the down or up arrow on the 4-way controller, if needed, to highlight the PC Connect Mode you want.
- 2 Press the left (Select) soft key. The checkmark moves to the highlighted mode, and you return to the Preferences menu. The camera is now set to the mode you just selected.

**Figure 76:** Set Date & Time Submenu



**Note:** Press the up or down arrow on the 4-way controller to scroll through the numbers on the left side of the screen. Press the right or left arrow to move between the date/time fields in the center of the screen.

## Setting the Date and Time


Use the Set Date & Time submenu to set the camera's date and time. If you wish to change the format that is used for the date and time, see the next subsection, "Format Dialog."

Press the up or down arrow on the 4-way controller to scroll through the list of numbers on the left side of the screen until you reach the number you want. The number in the currently highlighted field in the center of the screen (such as the Month field, as shown in the example in Figure 76) changes accordingly. When you have selected the number for the currently highlighted field, press the right arrow on the 4-way controller to move to the next field. When you have finished setting the date and time, press the right (Exit) soft key to save the date and time settings and return to the Preferences menu.

For example, to set the date to September 18, 2000 and the time to 2:51 pm, as shown in the example in Figure 76:

- 1 Press the up or down arrow on the 4-way controller until you highlight **9**, which sets the Month field in the center of the screen to 9 (for the month of September).
- 2 Press the right arrow on the 4-way controller to move to the Day field.
- 3 Press the up or down arrow on the 4-way controller until you highlight **18**.
- 4 Press the right arrow on the 4-way controller to move to the Year field.
- 5 Press the up or down arrow on the 4-way controller until you highlight **00**.
- 6 Press the right arrow on the 4-way controller to move to the Hour field.
- 7 Press the up or down arrow on the 4-way controller until you highlight **02**.
- 8 Press the right arrow on the 4-way controller to move to the Minutes field.
- 9 Press the up or down arrow on the 4-way controller until you highlight **51**.  
Since the am/pm setting is set to pm by default, simply leave the am/pm field as it is.
- 10 Press the right (Exit) soft key to save the date and time settings and return to the Preferences menu.

Figure 77: Format Dialog



## Format Dialog

When you press the left (Format) soft key in the Set Date & Time submenu, you see the Format dialog, which allows you to select from a list of six, predefined date and time formats. There are three formats which use the 24-hour clock format, and three formats which use the 12-hour clock format. The default format for the date and time is MM/DD/YY 12 hr, which means the date is in the Month/Day/Year format, and the time is in the 12-hour clock format.

For example, to set your camera to the MM/DD/YY 24 hour format (so that the date will be in the Month/Day/Year format, and the time will be in the 24-hour clock format), follow these steps:

- 1 Press the left (Format) soft key in the Set Date & Time submenu to move to the Format dialog.
- 2 Press the up or down arrow on the 4-way controller to highlight the MM/DD/YY 24 hours format in the Format dialog.
- 3 Press the left (Select) softkey, The checkmark moves to the highlighted date and time format, and you return to the Set Date & Time submenu. The camera is now set to the date and time format you just selected.

## Setting the Image Counter

Use the Image Counter submenu to set how the image counter works. You can set the camera either to restart numbering at 1 (one) each time you delete all the images from your camera, or to keep a continuous count of images from the beginning of the camera's use.

Table 64 explains the Image Counter settings and their functions. The currently selected setting is indicated by the checkmark to the left of it. The default setting is Continuous Counter.

Figure 78: Image Counter Submenu




Table 64: Image Counter Submenu

Setting	Function
Reset When Empty	Each time you delete all of the images on your camera, the counter restarts the first image captured at number 1.
Continuous Counter (default)	The images are counted according to the history of the camera's use. For example: image #400 is the 400th image to be captured with this camera.

**Note:** Once you have changed the Image Counter setting, you must power the camera off and then on again for the new setting to take effect.

**Figure 79:** Camera Name Submenu



**Note:** If a group name is applied to an image, then the group name, rather than the camera name, appears in the image information area of the Review Mode screen.

**Note:** Words wrap to the next line when they get too long.

To change the Image Counter setting:

- 1 Press the down or up arrow on the 4-way controller, if needed, to highlight the Image Counter setting you want.
- 2 Press the left (Select) soft key. The checkmark moves to the highlighted setting, and you return to the Preferences menu.
- 3 Power the camera off and then on again for the new setting to take effect.

## Naming Your Camera

Use the Camera Name submenu to enter a unique name for your camera. The camera name is used to identify images in the Review mode when you have transmitted images from one camera to another. (See “Transmitting Images Between Two Cameras” on page 48 for more information.) The default camera name is Digita Camera.

For example, if you transmit images from camera B to camera A, camera B’s name appears in the image information area of the Review mode screen on camera A when any images from camera B are viewed on camera A. The camera name does *not* appear in the image information area when you view images in Review mode on the camera you used to capture them.

To name your camera:

- 1 Press the left arrow on the 4-way controller to delete the letters of the default camera name.
- 2 Press the left (Character Set Icon) soft key to toggle through the four character sets (capital letters, lowercase letters, numbers, or symbols) until you see the character set you want to use displayed in the left soft key label area on the overlay bar.
- 3 Press the:
  - ◆ Up or down arrow on the 4-way controller to scroll through the list of characters on the left side of the screen.
  - ◆ Right arrow on the 4-way controller to enter the selected character and advance the insertion point in the center of the screen.
  - ◆ Left arrow on the 4-way controller to back up and delete a character.
  - ◆ Middle (Space) soft key to create a space between words in the camera name.
- 4 Press the right (Exit) soft key to save the camera name you set and return to the Preferences menu.

## Selecting a Language

English is set as the default language that is used on the camera. Use the Language submenu to select a language from the list of installed languages.

To select a language:

- 1 Press the down or up arrow on the 4-way controller to highlight the language setting you want.
- 2 Press the left (Select) soft key. The checkmark moves to the highlighted language, and you return to the Preferences menu. The selected language is now used on the camera.

**Figure 80:** Language Submenu



**Figure 81:** Reset Settings Confirmation Screen



## Resetting Camera Settings

Use the Reset Settings option to reset all of the camera settings (except for the Language, the Format for the Set Date & Time, the PC Connect Mode, and the Video Preferences settings) to their defaults in one step.

When you select the Reset Settings option by pressing the left (Reset) soft key, you will see a confirmation of your choice to reset the camera settings (see Figure 81). You can either press the middle (Reset) soft key to reset the settings, or press the right (Cancel) soft key to exit the confirmation screen without resetting the settings, and return to the Preferences menu.

### Overview

This appendix covers the following topics:

- ◆ “Camera Specifications” on page 103
- ◆ “Battery Life” on page 106
- ◆ “HP Accessories for Powering the Camera” on page 107
  - ◆ “Using the HP AC Power Adapter” on page 108
  - ◆ “Using the HP NiMH Batteries and Recharger” on page 108
- ◆ “Storage Capacities of Memory Cards” on page 109

### Camera Specifications

The following table lists the specifications for the HP 618 digital camera.

Camera Dimensions	127.5mm (L) x 56.5mm (W) x 71.5mm (H) (5.0 in. x 2.8 in. x 2.2 in.)
Weight	300 g (10.6 oz.) without batteries and memory card
Zoom	<ul style="list-style-type: none"><li>◆ 3x optical, 2x digital zoom</li><li>◆ 5.2-16.5mm</li><li>◆ 34-108mm (35mm equivalent)</li><li>◆ Digital zoom: shooting 1.2/1.5/2x, playback 2x</li></ul>
Sensor	2.11 megapixel, 1/2.7" CCD
Color Depth	30-bit (10 bits x 3 colors)
Color Control	Full color, B&W (black and white), and Sepia
Resolution	<ul style="list-style-type: none"><li>◆ Full Size: 1600 x 1200 pixels</li><li>◆ 1/4: 800 x 600 pixels</li></ul>

HP Imaging Technology	<ul style="list-style-type: none"> <li>◆ Custom ASIC for higher-performance image processing</li> <li>◆ Image processing at 220,000,000 operations per image in &lt;math&gt;1/2&lt;/math&gt; second</li> <li>◆ Excellent enlargements at 8" x 10"</li> </ul>
Lens	<ul style="list-style-type: none"> <li>◆ PENTAX™ power zoom (9 elements in 8 groups; 2 aspherical elements)</li> <li>◆ f/2.4-f/4.0</li> <li>◆ TTL (through the lens) auto focus</li> </ul>
Image Type Settings	<ul style="list-style-type: none"> <li>◆ One Shot</li> <li>◆ Continuous</li> <li>◆ Timelapse</li> </ul>
Exposure Compensation	+/-2.0 EV (Exposure Value) in .5 steps
Shutter Speed	1/1000 to 4 seconds
Sensitivity	Auto, Fixed (100 or 200 ISO speed)
AE Metering	TTL AE (auto exposure) metering with choice of Average, Center-Weighted, or Spot
Viewfinder	<ul style="list-style-type: none"> <li>◆ Separate zooming optical viewfinder with diopter adjustment</li> <li>◆ Diopter adjustment from <math>-3m^{-1}</math> to <math>+1m^{-1}</math></li> <li>◆ Field of view: 85% (at 3m or 9.8 ft.)</li> </ul>
Focus	<ul style="list-style-type: none"> <li>◆ TTL contrast-detection auto focus</li> <li>◆ Normal: 0.5m (1.64 ft.) to infinity</li> <li>◆ Macro: 0.1m (0.33 ft.) to 0.6m (1.97 ft.)</li> <li>◆ Infinity</li> <li>◆ Manual focus: 0.1m (0.33 ft.) to infinity</li> </ul>
Flash	<ul style="list-style-type: none"> <li>◆ Built-in flash</li> <li>◆ Flash modes: Auto, Auto with Red-Eye Reduction, Forced On, Forced On with Red-Eye Reduction, Forced Off, Night, and Night with Red-Eye Reduction</li> <li>◆ Effective range: 0.3m (0.98 ft.) - 5.4m (18 ft.) at 5.2mm 0.3m (0.98 ft.) - 3.7m (12 ft.) at 16.5 mm</li> </ul>

Exposure Settings	Auto, Landscape Program, Portrait Program, Action Program, Aperture Priority, and Shutter Priority
Memory Card	CompactFlash™ card (Type I or Type II, Power level 0) shipped with camera
Timer	<ul style="list-style-type: none"> <li>◆ 10-second delay</li> <li>◆ 3-second delay with HP Remote Control (included)</li> </ul>
Sound	Capture and play back sound with 45 seconds of recording per image
White Balance	Auto, Daylight, Tungsten, and Fluorescent
Interfaces	<ul style="list-style-type: none"> <li>◆ USB connection to computers</li> <li>◆ HP JetSend and Digita infrared protocols</li> <li>◆ NTSC/PAL TV connections</li> <li>◆ Orientation sensor for automatic image rotation on TV, computers, and cameras</li> </ul>
Camera Operating System	Flashpoint Digita
Image LCD	<ul style="list-style-type: none"> <li>◆ 2" low temperature poly-silicon TFT color LCD with 130,338 pixels</li> <li>◆ Adjustable brightness control</li> <li>◆ Displays thumbnails or full screen images</li> </ul>
Image Control Functions	<ul style="list-style-type: none"> <li>◆ Create slideshows of images</li> <li>◆ Send images via HP JetSend infrared technology to JetSend-capable printers</li> <li>◆ Delete, protect, group, and categorize images</li> <li>◆ Watermark images with Date and Time, Text, or Logo stamps</li> </ul>
Status LCD	Displays battery status, flash mode, timer mode, auto focus mode, and pictures remaining
Power	<ul style="list-style-type: none"> <li>◆ 4 AA non-rechargeable batteries (included)</li> <li>◆ Optional: AC power adapter, or rechargeable NiMH batteries and recharger</li> </ul>

**Caution:** Use only AA photo lithium, high drain alkaline, or NiMH batteries in the HP 618 digital camera. Do *not* mix batteries of different types. Replace all 4 batteries at the same time; do *not* replace the batteries individually. Always follow all of the manufacturer’s instructions on the battery package when handling, recharging, or disposing of batteries.

## Battery Life

The life of the batteries you use in your HP 618 camera depends on how you use the camera and on the type of batteries you use. The following table provides estimates of battery life in a variety of usage scenarios, including:

- ◆ Light use in Capture mode (image LCD off, no flash)
- ◆ Moderate use in Capture mode (some use of image LCD and flash)
- ◆ Leaving the camera in the idle state (image LCD off)
- ◆ Using the camera in Review mode
- ◆ Using the camera in live view of Capture mode (image LCD on)

Usage Scenario	Photo Lithium	NiMH	High Drain Alkaline
Light Capture Mode (Shots)	810	450	230
Moderate Capture Mode (Shots)	500	280	150
Idle State (Minutes)	600	300	300
Review Mode (Minutes)	220	120	90
Live View Capture Mode (Minutes)	120	85	45

To preserve battery life:

- ◆ Limit the use of the image LCD, or turn it off.
- ◆ Limit the use of the flash, or turn it off.
- ◆ Set the camera to take lower resolution and/or lower quality images. (See “File Settings Sub-menu” on page 53.) Higher resolution and higher quality images take the camera longer to process and compress.
- ◆ Limit operating the camera in cold temperature conditions. Operating the camera at colder temperatures results in shorter battery life.
- ◆ Always replace all 4 batteries at the same time. One low-charged battery will reduce battery life for all batteries in the camera. This is true of both non-rechargeable and rechargeable batteries.
- ◆ Use the HP-approved AC power adapter with your camera instead of batteries, or use rechargeable batteries. The following section lists the HP-approved accessories you can use for powering the camera.

**Note:** An AC power adapter provides power to the camera – it does *not* recharge the batteries.

**Caution:** Using a non-HP AC power adapter will void your camera's warranty.

## HP Accessories for Powering the Camera

You can purchase any of the following accessories for powering the camera, as well as other camera accessories, from the HP Shopping Village website at: [www.hpshopping.com](http://www.hpshopping.com). (Click the **Digital Photography** link on the main web page. Then click the **Digital Photography Accessories** link on the second web page.)

This table of power accessories was current at the time this manual was published. For the most up-to-date accessories list, refer to the HP Shopping Village website.

HP Model Number	Accessory	Specifications
A610	HP AC Power Adapter (See the next section, "Using the HP AC Power Adapter")	Input: 100-240 Volts AC Output: 9 Volts DC, 1.33 Amps, 12 Watts
AA30	HP NiMH Battery Recharger and 4 NiMH Batteries (See "Using the HP NiMH Batteries and Recharger" on page 108)	HP NiMH Battery Recharger: Recharging time is approximately 3.5 hours Input: 9 Volts DC Output (charging voltage): 8.4 Volts DC  HP NiMH Battery: 1.2 Volts DC (each)

**Figure 82:** Connecting the HP AC Power Adapter's Cable to the Camera



**Note:** Use the HP-approved AC power adapter as the power source for the camera during power-intensive operations, like when you are using the camera's image LCD for an extended period of time.

## Using the HP AC Power Adapter

To connect the HP AC Power Adapter to the camera:

- 1 Plug the AC power adapter into a power source, such as a wall outlet or power strip.
- 2 Open the door to the connector compartment on the camera. The connector compartment is located on the far right side of the camera when you are looking at the front of the camera.
- 3 Connect the round end of the AC power adapter's cable to the middle (power adapter) connector in the camera (see Figure 82).

## Using the HP NiMH Batteries and Recharger

If you purchase the HP NiMH Battery Recharger, which includes 4 rechargeable NiMH batteries, please note the following:

- ◆ Before you install the batteries in the HP 618 camera, you must charge all 4 NiMH batteries in the HP NiMH Battery Recharger per the instructions that came with the Battery Recharger.
- ◆ You must recharge all 4 NiMH batteries after fully draining them four times for the batteries to reach their optimum capacity and performance.
- ◆ Always recharge all 4 NiMH batteries at the same time. One low-charged battery will reduce the battery life for all 4 batteries in the camera.
- ◆ Do not store the batteries in the HP NiMH Battery Recharger for an extended period of time if it is not necessary.
- ◆ Do not over-charge the batteries. Disconnecting and reconnecting the HP NiMH Battery Recharger to AC power frequently, without discharging the batteries, may cause over-charging.
- ◆ Do not expose the NiMH batteries to heat. Permanent damage will result if the batteries are exposed to temperatures above 110° F or 43° C. Always store the batteries in a cool location.
- ◆ After long-term storage, recharge all 4 NiMH batteries before use. This is because the battery cells discharge over time. (At room temperature, NiMH batteries generally discharge at about 1% per day.)

## Storage Capacities of Memory Cards

The following table lists the number of images an 8 MB, 16 MB, and 32 MB CompactFlash memory card can store, depending on the JPEG quality level or TIFF setting at which the camera is set.

The number of images noted in this table are averages. In particular, the number of images per memory card can vary based on the JPEG compressed file size of each image.

**Note:** To make the most memory available on a memory card, reformat the card either on the camera (using the Format Card option in the Preferences menu – see page 68), or through the computer (using USB Disk Drive mode, reformat the card as you would a disk drive – see page 69).

	Resolution	JPEG-Good Quality Level	JPEG-Better Quality Level	JPEG-Best Quality Level	TIFF
8 MB Card	Full Size	27	14	7	1
	1/4	82	50	28	5
16 MB Card	Full Size	56	29	15	2
	1/4	165	101	57	10
32 MB Card	Full Size	113	60	30	5
	1/4	332	204	115	21

### Limited Product Warranty

HP Product	Duration of Limited Warranty
HP 618 digital camera	1 year
CompactFlash memory card	1 year
HP Photo Imaging Software	90 Days

#### A. Extent of Limited Warranty

- 1 Hewlett-Packard (HP) warrants to the end-user customer that the HP products specified above will be free from defects in material and workmanship for the duration specified above, which duration begins on the date of purchase by the customer.
- 2 For software products, HP's limited warranty applies only to a failure to execute programming instructions. HP does not warrant that the operation of any product will be uninterrupted or error free.
- 3 HP's limited warranty covers only those defects which arise as a result of normal use of the product, and does not cover any other problems, including those which arise as a result of:
  - a. Improper maintenance or modification;
  - b. Software, media, parts, or supplies not provided or supported by HP; or
  - c. Operation outside the product's specification.
- 4 If HP receives, during the applicable warranty period, notice of a defect in any product which is covered by HP's warranty, HP shall either repair or replace the defective product, at HP's option.

- 5 If HP is unable to repair or replace, as applicable, a defective product which is covered by HP's warranty, HP shall, within a reasonable time after being notified of the defect, refund the purchase price for the product.
- 6 HP shall have no obligation to repair, replace, or refund until the customer returns the defective product to HP.
- 7 Any replacement product may be either new or like-new, provided that it has functionality at least equal to that of the product being replaced.
- 8 HP products may contain remanufactured parts, components, or materials equivalent to new in performance.
- 9 HP's limited warranty is valid in any country where the covered HP product is distributed by HP. Contracts for additional warranty services, such as on-site service, are available from any authorized HP service facility in countries where the product is distributed by HP or by an authorized importer.

#### B. Limitations of Warranty

- 1 TO THE EXTENT ALLOWED BY LOCAL LAW, NEITHER HP NOR ITS THIRD PARTY SUPPLIERS MAKE ANY OTHER WARRANTY OR CONDITION OF ANY KIND, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THE HP PRODUCTS, AND SPECIFICALLY DISCLAIM THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE.

#### C. Limitations of Liability

- 1 To the extent allowed by local law, the remedies provided in this Warranty Statement are the customer's sole and exclusive remedies.
- 2 TO THE EXTENT ALLOWED BY LOCAL LAW, EXCEPT FOR THE OBLIGATIONS SPECIFICALLY SET FORTH IN THIS WARRANTY STATEMENT, IN NO EVENT SHALL HP OR ITS THIRD PARTY SUPPLIERS BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY AND WHETHER ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## D. Local Law

- 1 This Warranty Statement gives the customer specific legal rights. The customer may also have other rights which vary from state to state in the United States, from province to province in Canada, and from country to country elsewhere in the world.
- 2 To the extent that this Warranty Statement is inconsistent with local law, this Warranty Statement shall be deemed modified to be consistent with such local law. Under such local law, certain disclaimers and limitations of this Warranty Statement may not apply to the customer. For example, some states in the United States, as well as some governments outside the United States (including provinces in Canada), may:
  - a. Preclude the disclaimers and limitations in this Warranty Statement from limiting the statutory rights of a consumer (e.g. the United Kingdom);
  - b. Otherwise restrict the ability of a manufacturer to enforce such disclaimers or limitations; or
  - c. Grant the customer additional warranty rights, specify the duration of implied warranties which the manufacturer cannot disclaim, or not allow limitations on the duration of implied warranties.
- 3 FOR CONSUMER TRANSACTIONS IN AUSTRALIA AND NEW ZEALAND, THE TERMS IN THIS WARRANTY STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT, OR MODIFY, AND ARE IN ADDITION TO, THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THE HP PRODUCTS TO SUCH CUSTOMERS.

## Hewlett-Packard Year 2000 Warranty

### For Consumer Products Distributed Through Authorized Resellers

Subject to all of the terms and limitations of the HP Limited Warranty Statement provided with this HP Product, HP warrants that this HP Product will be able to accurately process date data (including, but not limited to, calculating, comparing and sequencing) from, into, and between the twentieth and twenty-first centuries, and the years 1999 and 2000, including leap year calculations, when used in accordance with the Product documentation provided by HP (including any instructions for installing patches or upgrades), provided that all other products (e.g. hardware, software, firmware) used in combination with such HP Products(s) properly exchange date data with it. The duration of the Year 2000 warranty extends through January 31, 2001.

### Safety Information

#### Using Batteries

The HP 618 digital camera comes with four non-rechargeable batteries. Do *not* attempt to recharge these batteries. Do *not* mix old and new batteries or batteries of different types. Follow the battery manufacturer's safety instructions.

#### Disposing or Recycling of Batteries

Follow the battery manufacturer's disposal and recycling instructions or the guidelines that are recommended for your area. Do *not* incinerate or puncture batteries.

#### Using an AC Power Adapter

Use only the HP-approved AC power adapter. Failure to do so could cause damage or destroy the camera and cause a fire. Use of a non-HP AC power adapter will also void your camera's warranty.

#### Mercury Disclosure Statement

The image LCD of the HP 618 digital camera contains mercury. Disposal of this material may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or EIA: [www.eiae.org](http://www.eiae.org).

## Regulatory Notices

### U.S.A.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Canada

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled Digital Apparatus, ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur les matériels brouilleurs: Appareils Numériques, NMB-003 édictée par le ministre de la Communication.

<b>4-way controller</b>	A button on the back of the camera that has four directional arrows (up, down, right, and left) that you can press to navigate the menus and images displayed in the image LCD.
<b>AC power adapter</b>	Alternating Current power adapter. A power transformer that provides power to the digital camera and preserves battery life. (Note that the AC power adapter does <i>not</i> recharge the batteries.)
<b>Action Program exposure mode</b>	The exposure mode setting in the Photo Assist menu that automatically optimizes the camera settings for taking pictures of subjects in action, such as people playing sports. See also “exposure modes” on page 116.
<b>AE Metering</b>	Automatic Exposure Metering. A setting in the Photo Assist menu that determines the area of the scene used to set the exposure for a capturing an image.
<b>aperture</b>	The variable diameter opening in a camera lens that lets you control the intensity of light reaching the film or CCD. A camera's aperture and shutter speed determine a photo's exposure. Aperture diameters are expressed in f-numbers – the larger the f-number, the smaller the lens opening. Dividing the focal length of a lens by a specific f-number gives its aperture diameter. See also “CCD” on page 116, “f-number” on page 117, and “focal length” on page 117.
<b>Aperture Priority (Av) exposure mode</b>	The exposure mode setting in the Photo Assist menu that lets you select an aperture, and the camera automatically selects the shutter speed. See also “aperture” on page 115, “exposure modes” on page 116, “shutter” on page 121, and “Shutter Priority (Tv) exposure mode” on page 121.
<b>Auto exposure mode</b>	The exposure mode setting in the Photo Assist menu where all settings are at their defaults and cannot be changed. See also “exposure modes” on page 116.
<b>Auto Focus mode</b>	The default focus mode of the camera that automatically focuses the camera lens on a picture subject. You can change the focus mode to Manual Focus in the Photo Assist menu. See also “Manual Focus mode” on page 119.
<b>auto focus range</b>	This focus range is set by pressing a status LCD button on top of the camera and determines whether the focus is set for infinity (picture of a distant subject), for macro (a close-up picture of a subject), or for normal focus range.
<b>auto focus range button</b>	A status LCD button on the top of the camera that you press to set the auto focus range.
<b>auto focus range icon</b>	An icon that appears in the status LCD and shows the camera's current auto focus range.
<b>automatic exposure (AE)</b>	The camera feature that calculates the necessary shutter speed, aperture, and ISO speed to get the best possible exposure.
<b>automatic shutoff</b>	A feature that automatically shuts off the camera after a certain period in order to preserve battery power.
<b>Av</b>	See “Aperture Priority (Av) exposure mode” on page 115.
<b>battery status</b>	The amount of power that remains in the battery.

**battery status icon**

An icon that appears in the status LCD that indicates the amount of power left in the batteries.

**camera mode dial**

The dial on the top of the camera that allows you to choose one of four operational modes (Capture, Review, Playback, or PC Connect mode) for the camera.

**Capture mode**

An operational mode you use to take pictures (or “capture images”) with the camera. See also “camera mode dial” on page 116.

**CCD**

Charge Coupled Device. An integrated micro-electronic, light-sensing device built into a digital camera. The CCD image sensor is a silicon chip containing hundreds-of-thousands to a few million light-sensitive cells that convert light to electricity. A CCD sensor, combined with the digital image processing capability, is the functional equivalent of film in a digital camera.

**CCD element**

A single photosensitive area within a CCD array that is able to record a unique image detail. Also known as a photosite. See also “CCD” on page 116.

**Continuous image type**

The image type setting on the camera that captures a series of images in rapid succession. This image type is recommended for capturing action shots. See also “image type” on page 118.

**default**

A setting that the camera automatically uses until you change it.

**Delete**

A command associated with a soft key that is used to erase marked images or the current image from the memory card.

**digital zoom**

Refers to digital cropping of the image, giving the appearance of greater zoom. After the optical zoom is at its maximum setting, you can digitally zoom in three steps (1.2x, 1.5x, and 2.0x). The image LCD must be on in order for the digital zoom to operate. Note that, in digital zoom mode, enlargement is accomplished without changes in lens configuration. Since the lens is not involved in digital zoom, the changes appear only in the image LCD; they are not evident through the viewfinder. See also “optical zoom” on page 120.

**diopter control**

A small dial next to the viewfinder that you can turn to adjust the focus of the picture subject in the viewfinder. Note that the diopter control has no effect on the image you capture, however.

**DISPLAY button**

A button on the back of the camera that turns the image LCD on and off in Capture mode, and turns the overlay bars on and off in Playback mode. This button is inactive in Review and PC Connect modes. See also “image LCD” on page 118.

**exposure modes**

The modes that you can select in the Photo Assist menu to set the camera exposure to properly capture images, including: Auto, Landscape Program, Portrait Program, Action Program, Aperture Priority (Av), and Shutter Priority (Tv). See also “Action Program exposure mode” on page 115, “Aperture Priority (Av) exposure mode” on page 115, “Auto exposure mode” on page 115, “Landscape Program exposure mode” on page 119, “Portrait Program exposure mode” on page 120, and “Shutter Priority (Tv) exposure mode” on page 121.

**file name**

A set of letters, numbers, and symbols assigned to a file to distinguish it from other files on the computer or in the camera.

<b>file size</b>	The number of bytes in a file. The file size for images saved on a digital camera is determined by the resolution of the camera's CCD and the amount of image data compression. You can usually select the amount of compression on the camera and again in the computer software that processes the images. Note that if you compress an image on the camera and in the software, the compression is cumulative.
<b>file type</b>	The digital format in which a file is saved. Computer programs can insert or import files that were saved in a file type that the program supports. Common file types for images include JPEG (Joint Photo Expert Group format) and TIFF (Tagged Image File Format). See also "JPEG" on page 118 and "TIFF" on page 122.
<b>firmware</b>	The low-level software that runs in a digital camera and controls the functionality and user interface on the camera.
<b>firmware update</b>	The process of updating to a new firmware version on the digital camera.
<b>flash</b>	A brief, intense burst of light from an electronic flash unit on a camera. Use flash when the lighting in a scene is inadequate for taking pictures.
<b>flash mode</b>	This mode is set by pressing a status LCD button on top of the camera and determines how the flash will operate.
<b>flash mode button</b>	A status LCD button on the top of the camera that you press to set the flash mode.
<b>flash mode icon(s)</b>	An icon or set of icons in the status LCD that shows the current flash mode.
<b>f-number</b>	The f-number (also called the f-stop) is related to the diameter of the lens aperture – dividing the focal length of the lens by the f-number specifies the aperture diameter. The f-number is used in conjunction with the shutter speed to set the exposure. A standard set of f-numbers is commonly used in camera lenses. A lower f-number, such as f/2.8, indicates a larger aperture, which lets in more light. A higher f-number, such as f/16, indicates a smaller aperture, which lets in less light. See also "aperture" on page 115 and "focal length" on page 117.
<b>focal length</b>	The distance between the center of the lens (more precisely, its rear nodal point) and the CCD sensor in digital cameras when the lens is focused on infinity. The focal length is specified in millimeters.
<b>focus</b>	Refers to adjusting the lens in a digital camera in order to place a clear image on the plane of the CCD sensor.
<b>focus mode</b>	See "Auto Focus mode" on page 115 and "Manual Focus mode" on page 119.
<b>focus range</b>	See "auto focus range" on page 115.
<b>four-way controller</b>	See "4-way controller" on page 115.
<b>f-stop</b>	See "f-number" on page 117.
<b>grouped images</b>	A number of images that are bundled together. You can group images in the Edit menu of Review mode. Grouped images appear in a folder on the memory card when the camera is connected to a computer.

<b>icon</b>	State-of-the-art image processing technology developed by HP that captures sharp, colorful images with exceptional levels of detail, individually optimizes every image, and produces great detail in highlights and shadows.
<b>image</b>	A picture on an LCD, computer screen, or printed on a device that represents a specific setting. Icons on a digital camera's LCD communicate the camera's status, such as particular settings that have been made for taking a picture. See also "LCD" on page 119.
<b>image LCD</b>	The electronic version of a photograph as it is stored in a digital camera, computer, or other electronic medium. Digital cameras capture and store an image when you take a picture. See also "picture" on page 120 and "photo" on page 120.
<b>image size</b>	The Liquid Crystal Display on the back of the camera. The image LCD and its accompanying buttons and soft keys let you view and work with images on the camera. See also "DISPLAY button" on page 116, "MENU button" on page 119, and "soft keys" on page 122.
<b>image type</b>	See "size" on page 122.
<b>image type icon</b>	The type of image the camera will capture. There are three image types: One Shot, Continuous, and Timelapse. You can change the image type by pressing the left soft key while in Capture mode. See also "Continuous image type" on page 116, "One Shot image type" on page 119, and "Timelapse image type" on page 123.
<b>image type soft key</b>	An icon that appears on the left side of the bottom overlay bar in the image LCD and shows the image type setting in Capture mode.
<b>infrared</b>	The left soft key on the back of the camera that you press to set the image type in Capture mode.
<b>infrared window</b>	A type of connection that allows images to be transmitted between the camera and another device (such as a printer) without connecting wires when the infrared window on the camera is lined-up with an infrared sensor on the other device. See also "JetSend" on page 118.
<b>interval</b>	The window on the front of the camera that uses the HP JetSend infrared technology. See also "JetSend" on page 118.
<b>ISO number</b>	The time between images being captured for the Timelapse image type.
<b>JetSend</b>	The International Organization for Standardization rating for film or CCD sensitivity. A higher ISO number means less light is needed to take a picture. CCDs in digital cameras are rated in terms of ISO numbers. ISO is not an acronym; it is derived from the Greek "isos", meaning equal. See also "CCD" on page 116.
<b>JPEG</b>	A protocol developed by HP for sending image data from one device to another without using any connecting cables between the devices. JetSend uses infrared technology to transmit images from the camera to a printer for printing.
	A compressed image file format developed by the Joint Photo Expert Group. Its strengths are very small file sizes and fast display rates. (It is 7 to 10 times faster than some other image file formats.) See also "file type" on page 117 and "TIFF" on page 122.

## Landscape Program exposure mode

The exposure mode setting in the Photo Assist menu that automatically optimizes the camera settings for taking pictures of distant subjects, such as landscape scenes. See also “exposure modes” on page 116.

## LCD

Liquid Crystal Display. A display technology that is used on digital cameras. An LCD displays numeric characters and/or icons to communicate the camera's status, such as the particular settings that you have made for taking a picture. See also “image LCD” on page 118 and “status LCD” on page 122.

## LED

Light Emitting Diode. An indicator on the camera that shows the status of some feature or process by either lighting solid or blinking on and off.

## lens

One or more pieces of optical glass or similar material designed to collect and focus rays of light to form a sharp image on the film (for traditional film cameras) or the CCD (for digital cameras). Lenses are rated according to their maximum aperture (smallest possible f-number) and their focal length (usually specified in millimeters). See also “aperture” on page 115, “CCD” on page 116, and “f-number” on page 117.

## live view

Using the image LCD on the back of the camera to view the picture subject before taking the picture.

## Manual Focus mode

The focus mode that you set in the Photo Assist menu that lets you control the focus distance of the lens when capturing images. See also “Auto Focus mode” on page 115.

## marking

Specifying an image or several images to which you will then apply a single action.

## memory card

A small removable, non-volatile storage medium for digital information that acts as the film in a digital camera. The memory card stores the images so you can process or view them at a later time. Make sure the camera is powered *off* any time you remove the memory card from the camera.

## memory card access LED

The LED that blinks to indicate the memory card is in use. See also “LED” on page 119.

## memory card door

The door on the side of the camera that you open to access the memory card in the camera.

## MENU button

A button on the back of the camera that lets you view menus on the image LCD in the Capture, Review, or Playback mode. See also “modes” on page 119.

## menus

These appear on the image LCD when you press the MENU button in the Capture, Review, or Playback mode and are used to choose and set camera settings.

## microphone

The audio device on the front of the camera used to record sound that is then attached to an image.

## mode dial

See “camera mode dial” on page 116.

## modes

These set the way the camera functions. There are four operational modes: Capture, Review, Playback, and PC Connect.

## NTSC connection

National Television Standards Committee connection. The video (TV) connection standard used in the United States and Japan.

## One Shot image type

The image type setting on the camera that captures one image at a time. See also “image type” on page 118.

<b>optical resolution</b>	The true resolution of an imaging device, and the resolution at which the device captures images. See also “resolution” on page 121.
<b>optical zoom</b>	The process of changing the field of view and magnification of the lens by moving different lens groups within the lens to change its overall focal length. See also “digital zoom” on page 116.
<b>orientation sensor</b>	An electro-mechanical device in the camera that determines whether the camera is being held horizontally or vertically, and which side is up. The camera uses the data from this sensor to make sure the image is displayed right side up in the image LCD, regardless of the camera position when the image was captured.
<b>overlay bars</b>	Opaque or translucent information bars that appear on the image LCD.
<b>PAL connection</b>	Phase Alternating Line connection. The video (TV) connection used in Europe.
<b>PC Connect mode</b>	An operational mode you use to control the camera via a computer (PC or Macintosh) that you have connected to the camera. You use this mode to download images from the camera to the computer. See also “camera mode dial” on page 116.
<b>PCMCIA adapter</b>	Personal Computer Manufacturers Common Interface Agreement adapter. A small, electronic card that fits in a PCMCIA slot and controls or communicates with an external device. For digital cameras, this is usually an adapter into which you can plug the memory card from the camera for transferring images to your computer.
<b>PCMCIA slot</b>	The slot in a computer that holds a PCMCIA card. A PCMCIA slot is usually found in laptop computers.
<b>photo</b>	The printed version of an image. See also “image” on page 118 and “picture” on page 120.
<b>photo type</b>	See “image type” on page 118.
<b>photosite</b>	See “CCD element” on page 116.
<b>picture</b>	Picture refers to the original composition when capturing an image with a digital camera. See also “image” on page 118.
<b>pictures remaining indicator</b>	A numeric indicator in the status LCD that shows how many more images you can capture and store on the memory card.
<b>pixel</b>	Picture element. The smallest element that can be assigned an independent color and intensity and displayed on a computer monitor screen or on an LCD. A pixel is a dot with either a square or rectangular shape. Digital images displayed on a monitor screen or LCD are composed of thousands of pixels.
<b>Playback mode</b>	An operational mode you can use to view the captured images on the camera’s image LCD. You can view images as full-sized stills, play back timelapse and grouped photo sequences, and create slideshows of the images. See also “camera mode dial” on page 116 and “slideshow” on page 122.
<b>Portrait Program exposure mode</b>	The exposure mode setting in the Photo Assist menu that automatically optimizes the camera settings for portrait photography. See also “exposure modes” on page 116.

<b>power switch</b>	The switch on the camera that turns it on or off.
<b>preview</b>	See “live view” on page 119.
<b>protect</b>	Marking an image so that no one can delete it.
<b>record button</b>	See “sound record button” on page 122.
<b>red-eye</b>	Refers to a human’s or animal’s eyes that appear red in captured images, which is caused by using the flash on a camera.
<b>red-eye reduction</b>	A flash mode you can use to minimize red-eye in captured images of humans or animals. The camera does this by flashing twice. See also “flash mode” on page 117.
<b>reformat</b>	Reformatting completely erases the memory card, including all images (protected and unprotected) and all other files.
<b>remote control</b>	A device used to trigger the shutter from a location that is remote from the camera, such as when you want to take a self portrait or want to be in a group picture. When you press the HP Remote Control’s trigger, the image capture is delayed by a length of time specified by the timer mode. See also “timer mode” on page 123.
<b>resolution</b>	The measure of how many pixels are displayed or printed. The resolution of a CCD is determined by multiplying the X pixels by the Y pixels. The greater the resolution, the greater the amount of detail visible, and the larger the file size. The final output device (computer monitor or printer) on which an image is displayed or printed determines the actual resolution you will see. For example, if you capture an image at 1600 x 1200 pixels, and your printer is capable of printing at only 300 dpi (dots per inch), the printed image will be no more than 300 dpi.
<b>review</b>	The process of using the image LCD to view the images stored on the memory card.
<b>Review mode</b>	An operational mode you can use to sort and edit the captured images on the camera. See also “camera mode dial” on page 116.
<b>self-timer</b>	See “timer” on page 123.
<b>Send button</b>	A button on the back of the camera you can use to send images from the camera to a printer via the HP JetSend infrared technology. The Send button is active in the Capture, Review, and Playback modes. See also “JetSend” on page 118.
<b>shutter</b>	A set of surfaces that block light from the film or CCD in a camera. When the shutter is released, the surfaces open for a predefined time, admitting a measured amount of light. See also “CCD” on page 116.
<b>Shutter Priority (Tv) exposure mode</b>	An exposure mode setting in the Photo Assist menu that lets you select a shutter speed, and the camera automatically selects the aperture setting. See also “aperture” on page 115, “Aperture Priority (Av) exposure mode” on page 115, “shutter” on page 121, and “shutter speed” on page 122.

**shutter release button**

A two-stage button on the top of the camera that is enabled in Capture mode. Pressing this button halfway down allows the camera to make various settings, such as Auto Focus Lock. Pressing this button all the way down in one motion allows the camera to make various settings and to capture one or more images, depending on the image type selected. The camera makes a shutter sound as each image is captured.

**shutter speed**

The amount of time the shutter stays open when you press the shutter release button.

**size**

The actual height and width of an image when you have saved the image. You will not see the image size change in the image LCD after you save it.

**sleep mode**

A feature that conserves battery power by automatically shutting off the image LCD after a period of time (default 2 minutes) that the camera hasn't been used.

**slideshow**

The sequential viewing of images stored on the camera's memory card in Playback mode.

**soft keys**

Three buttons that are located just below the image LCD on the back of the camera. The soft keys let you work with images and menus on the image LCD. See also "image LCD" on page 118.

**sound record button**

A button on the back of the camera that allows you to record sound that is then attached to an image.

**speaker**

The audio device on the back of the camera that allows you to hear the camera's system sounds (shutter clicks, beeps, and so forth). It also allows you to hear sound that was previously recorded and attached to an image via the camera's sound record button.

**status LCD**

The Liquid Crystal Display on the top of the camera that uses a combination of numeric characters and icons to communicate the camera's status, such as particular camera settings.

**status LCD buttons**

The three buttons beneath the status LCD that you can press to set the flash mode, timer mode, and auto focus range. See also "auto focus range button" on page 115, "flash mode button" on page 117, and "timer mode button" on page 123.

**strobe**

See "flash" on page 117.

**subject**

The main object, person, or scene that you want to capture with your camera.

**telephoto**

A lens that has a longer focal length and narrower field of view (includes less subject area) than a normal lens. A telephoto lens makes a subject appear larger and/or closer than does a normal lens at the same camera-to-subject distance. See also "wide angle" on page 124.

**thumbnail**

A miniature of the original image that is large enough to allow you to identify the image, but is small enough to allow you to see multiple images in a single software window. Thumbnails are used to display on-screen images of the contents of a digital camera's memory card.

**TIFF**

Tagged Image File Format. A bitmapped file format for images. TIFF does not compress the image. TIFF files are supported by many programs and can also be used on many types of computers. See also "file type" on page 117 and "JPEG" on page 118.

<b>Timelapse image type</b>	The image type setting on the camera that captures a slow process with a series of images. See also “image type” on page 118.
<b>timer</b>	A device that lets you take a self portrait or be in a group picture. When you press the shutter release button or the HP Remote Control’s trigger, the image capture is delayed by a length of time specified by the timer delay. See also “timer delay.”
<b>timer delay</b>	The amount of time the camera waits to take the picture when using the timer.
<b>timer LED</b>	The Light Emitting Diode on the front of the camera that flashes to indicate the countdown of the timer delay when you have set the timer and then pressed the shutter release button or the HP Remote Control’s trigger.
<b>timer mode</b>	This mode is set by pressing a status LCD button on top of the camera and determines how the shutter release button will be triggered.
<b>timer mode button</b>	The status LCD button on the top of the camera that you press to set the timer mode.
<b>timer mode icon(s)</b>	An icon or set of icons that appears in the status LCD and shows the current timer mode.
<b>Tv</b>	See “Shutter Priority (Tv) exposure mode” on page 121.
<b>TV (video) connection</b>	The connector into which you plug the video cable to connect the camera to a television (TV). See also “NTSC connection” on page 119 and “PAL connection” on page 120.
<b>unload</b>	The process of copying images from the memory card directly to the computer.
<b>unmark</b>	The process of deselecting images in the camera that have previously been marked.
<b>unprotect</b>	The process of removing the protection on images in the camera so that they can be deleted.
<b>USB</b>	Universal Serial Bus. An interface for connecting peripherals, such as digital cameras, to a computer.
<b>USB Mass Storage Device Class</b>	A Microsoft Windows device class that lets the operating system display the files in a camera as though they are stored on a separate, additional computer device similar to a disk drive.
<b>video cable</b>	The wire that can be used to connect the camera to a television.
<b>video input connector</b>	The connector on a television into which you plug the video cable.
<b>viewfinder</b>	The window on the back of the camera through which you look to frame the subject that will be recorded when you capture an image.
<b>wake up</b>	The process of bringing the camera out of sleep mode.

## White Balance

A setting in the Photo Assist menu that is used to correct the color applied to a captured image under different lighting conditions in order to make the white areas in the image appear white without any color cast.

## wide angle

A lens that has a shorter focal length and a wider field of view (including more subject area) than a normal lens. A wide angle lens makes a subject appear smaller than does a normal lens at the same camera-to-subject distance. See also “telephoto” on page 122.

## zoom

To enlarge the subject by changing the field of view and magnification of the lens by using the zoom lever. Once the camera lens is at maximum optical zoom, you can switch into digital zoom mode, if the image LCD is on. See also “optical zoom” on page 120 and “digital zoom” on page 116.

## zoom lever

A lever on the back of the camera that moves the lens continuously between telephoto and wide angle focal lengths. The zoom lever also controls the digital zoom. See also “digital zoom” on page 116, “focal length” on page 117, “telephoto” on page 122, and “wide angle” on page 124.

## Numerics

4-way controller, using 15

## A

AC power adapter

    purchasing from HP 107

    safety information 113

    using 108

Accessories for powering the camera 107

Add to Order submenu 82

AE Metering submenu 60

Aperture indicator 12

Auto focus range

    Macro and Infinity indicators 13

    setting 11

## B

Batteries

    purchasing from HP 107

    safety information 113

    using rechargeable 108

Battery life 106

Buttons

    4-way controller 15

    auto focus range 11

    flash mode 10

    timer mode 11

## C

Camera

    AC power adapter 107

    accessories 107

    battery life 106

    connecting television to 50

    firmware updates 7

    HP Year 2000 warranty 112

    limited product warranty 110

    NiMH batteries and recharger 107

    Preferences menu 94

    Reset Settings menu option 73, 102

    specifications 103

    Status screen, viewing 14

    transferring images to computer 38

    using Focus Lock 18

Camera Name submenu 72, 101

Camera-Camera menu option 84

Camera-Printer menu option 85

Capture mode menus

    accessing 52

    Capture Settings 52

    Image Stamp 62

    Photo Assist 55

    Preferences 66, 94

    using 15

Capture mode, setting the camera to 8

Capture Settings menu 52

Categories submenu 80

Categorizing images 35

Collapsing Timelapse or grouped images 31

Connecting

    camera to television 50

Continuous images, shooting 20

Customer Support Centers, HP 93

## D

Date and time, setting 70, 99

Date/Time Stamp submenu 62

Delete menu option 78

Deleting images 32

Dialogs

    Format for Set Date & Time 70, 100

    Logo Files 65

Digital Print Order Form (DPOF) 81

Digital zoom

    indicator on image LCD 13

Digital zoom, using 22

Diopter control, using 22

Display submenu 67, 95

Disposing of batteries 113

Dissolving image groups 33

DPOF (Digital Print Order Form) 81

## E

- Edit menu 78
- Erase Order menu option 83
- EV Compensation submenu 57
- Expanding Timelapse or grouped images 31
- Exposure mode indicator 12
- Exposure Mode submenu 56

## F

- File Settings submenu 53
- Find By Category submenu 87
- Find By Date submenu 87
- Find menu 86
- Firmware updates 7
- Flash mode, setting 10
- Focus Lock, using 18
- Focus Mode submenu 59
- Focus range, auto 11
- Focus, Manual 12
- Format Card menu option 68, 98
- Format dialog, Set Date & Time submenu 70, 100

## G

- Group Name submenu 79
- Grouped images
  - expanding or collapsing 31
  - viewing 28
- Grouping images 33, 79

## H

- HP Customer Care 93
- HP JetSend 46
- HP Shopping Village website 107
- HP Year 2000 warranty 112

## I

- Image Counter submenu 71, 100
- Image LCD, using 12
- Image Stamp menu 62
- Image types
  - Continuous images 20
  - One Shot images 19
  - setting 13
  - soft key 13

- Timelapse images 21
  - viewing Timelapse in Playback mode 28

## Images

- categorizing 35
  - collapsing Timelapse or grouped 31
  - Continuous 20
  - creating slideshows 29
  - deleting 32
  - dissolving groups 33
  - expanding Timelapse or grouped 31
  - grouping 33, 79
  - JetSending to printer 46
  - marking 31
  - One Shot 19
  - protecting 34
  - searching for 36
  - selecting in Review mode 30
  - sharing 38
  - Timelapse 21
  - transferring to computer 38
  - unmarking 31
  - unprotecting 34
  - viewing full screen 28
  - viewing on television 51
  - viewing Timelapse and grouped 28
- Infinity auto focus range indicator 13
  - Instant Review, using 25
  - ISO Speed submenu 61

## J

- Jetsending images to printer 46

## L

- Language submenu 73, 102

## LCDs

- image LCD 12
- status LCD 9

## LEDs

- memory card access LED 24
- timer LED 24
- understanding 23
- viewfinder LED 23

- Light Emitting Diodes (LEDs) 23

Limited product warranty 110

Logo Files dialog 65

Logo Stamp submenu 65

## M

Macro auto focus range indicator 13

Manual focus 12

Marking images 31

Memory card access LED 24

Memory card, Format Card menu option 68, 98

Menus

- Capture mode 15, 52

- Capture Settings 52

- Edit 78

- Find 86

- Image Stamp 62

- Photo Assist 55

- Play Settings 74

- Playback mode 74

- Preferences 66, 94

- Print Order Form 81

- Review mode 78

- Transmit 84

Mercury disclosure statement 113

Modes

- Capture 8, 52

- Flash 10

- Playback 27, 74

- Review 27, 30, 78

- Timer 11

## N

NiMH batteries and recharger

- purchasing from HP 107

- using 108

## O

One Shot images, shooting 19

Output format, video 50

Overlay bars, using 12, 14

Overlay soft key 12

Overlay soft key, using 14

Overview

- camera introduction 5

- camera troubleshooting 88

- menu and soft key reference 52

- preparing to take pictures 8

- reviewing images 27

- sharing images 38

- taking pictures 16

## P

PC Connect Mode submenu 38, 69, 98

Photo Assist menu 55

Pictures

- advanced picture taking 17

- point-and-shoot picture taking 16

Play Settings menu 74

Playback mode

- accessing 27

- creating a slideshow 29

- viewing full screen images 28

- viewing Timelapse and grouped images 28

- zooming in on images 28

Playback mode menu

- accessing 74

- Play Settings 74

Playback Rate submenu 76

Point-and-shoot pictures 16

Preferences menu 66, 94

Print Order Form menu 81

Printer, JetSending images to 46

Problems, troubleshooting 88

Product safety information 113

Product warranty, limited 110

Protect menu option 79

Protecting images 34

## R

Rechargers, battery

- purchasing from HP 107

- using 108

Recording sound 26

Recycling batteries 113

Regulatory notices (USA & Canada) 114

- Removing grouping on images 33
- Reset Settings menu option 73, 102
- Review mode
  - accessing 27, 30
  - categorizing images 35
  - collapsing Timelapse or grouped images 31
  - deleting images 32
  - dissolving image groups 33
  - expanding Timelapse or grouped images 31
  - grouping images 33
  - marking images 31
  - protecting images 34
  - searching for images 36
  - selecting images 30
  - unmarking images 31
  - unprotecting images 34
- Review mode menus
  - accessing 78
  - Edit 78
  - Find 86
  - Print Order Form 81
  - Transmit 84
- Reviewing images 27
- S**
- Safety
  - AC power adapter 113
  - batteries 113
  - mercury disclosure statement 113
- Searching for images 36
- Selecting images in Review mode 30
- Set Date & Time submenu 70, 99
- Setting the format for date and time 70, 100
- Sharing images 38
- Shutter Speed indicator 12
- Slideshow submenu 75
- Slideshows, creating 29
- Soft keys
  - Add to Order submenu 82
  - AE Metering submenu 60
  - Camera Name submenu 72
  - Camera-Camera option 84
  - Camera-Printer option 85
  - Capture Settings menu 52
  - Categories submenu 80
  - Date/Time Stamp submenu 63
  - Delete option 78
  - Display submenu 67
  - Erase Order option 83
  - EV Compensation submenu 57
  - Exposure submenu 57
  - File Settings submenu 54
  - Find By Category submenu 87
  - Find By Date submenu 87
  - Find menu 86
  - Focus submenu 59
  - Format Card option 68
  - Format List dialog 70
  - Group Name submenu 79
  - Image Counter submenu 71
  - Image Stamp menu 62
  - image types 13
  - ISO Speed submenu 61
  - labels 12
  - Language submenu 73
  - Logo Files dialog 65
  - Logo Stamp submenu 65
  - Overlay 12, 14
  - PC Connect mode submenu 69
  - Photo Assist menu 55
  - Play Settings menu 74
  - Playback Rate submenu 76
  - Preferences menu 66
  - Print Order Form menu 81
  - Protect option 80
  - Reset Settings option 73
  - Set Date & Time submenu 70
  - Slideshow submenu 75
  - Sound submenu 68
  - Status 14
  - Text Stamp submenu 64
  - Timelapse Settings submenu 54
  - using 12

- Video Preferences submenu 77
- View Order option 83
- White Balance submenu 58
- Sound submenu 68, 97
- Sound, recording 26
- Specifications, camera 103
- Status LCD
  - auto focus range 11
  - flash mode 10
  - timer mode 11
  - using the buttons 9
- Status screen, viewing 14
- Status soft key 14
- Submenus
  - Add to Order 82
  - AE Metering 60
  - Camera Name 72, 101
  - Categories 80
  - Date/Time Stamp 62
  - Display 67, 95
  - EV Compensation 57
  - Exposure Mode 56
  - File Settings 53
  - Find By Category 87
  - Find By Date 87
  - Focus Mode 59
  - Group Name 79
  - Image Counter 71, 100
  - ISO Speed 61
  - Language 73, 102
  - Logo Stamp 65
  - PC Connect Mode 38, 69, 98
  - Playback Rate 76
  - Set Date & Time 70, 99
  - Slideshow 75
  - Sound 68, 97
  - Text Stamp 64
  - Timelapse Settings 54
  - Video Preferences 77
  - White Balance 58
- Support, HP customer 93

- T**
- Technical support, HP 93
- Television, connecting to camera 50
- Text message area, understanding 12
- Text Stamp submenu 64
- Time and date, setting 70, 99
- Timelapse images
  - expanding or collapsing 31
  - shooting 21
  - viewing 28
- Timelapse Settings submenu 54
- Timer LED 24
- Timer mode, setting 11
- Transferring images to a computer 38
- Transmit menu 84
- Troubleshooting common problems 88
- U**
- Unmarking images 31
- Unprotecting images 34
- Updates to firmware 7
- User's Guide
  - how to use it 7
  - related information 7
  - what's in it 6
- V**
- Video output format, selecting 50
- Video Preferences submenu 77
- View Order menu option 83
- Viewfinder LED 23
- Viewing images on television 51
- W**
- Warranty
  - HP Year 2000 112
  - limited camera 110
- Websites
  - HP Customer Care 93
  - HP Shopping Village 107
- White Balance submenu 58
- Z**
- Zoom lever, using 22