

Dos Flash 2M BIOS Standard Operation Procedure

1. Copy BIOS folder to USB Disk.
2. Boot system to DOS mode.
3. Enter BIOS folder.
4. Enter “/Dos” folder.
5. Execute “BIOS_2M.bat” file.
6. Process to flash BIOS.
7. Power off your system after flashing BIOS completely.
8. Power on then boot system.