



**BFW3000**

**3 Port 1394 Repeater**

**Hardware Guide**

***DESCRIPTION:***

---

The BFW3000 is 3 Port 1394 REPEATER

***Check your packing listing:***

---

BFW3000 x 1

Hardware Guide x 1

**\*\* If any of these items are missing from the BFW3000 Retail package, contact your supplier immediately.**

***Hardware Specification***

---

1394 3 PORT REPEATER, 400 Mbps speed support.

***TECHNICAL SPECIFICATION:***

---

**Compatibility:** -1394 Version A

**Operating system:** -WIN 98/SE, ME, 2000, XP


**Chips:** -FW803

**Connections:**  
Connector Type -1394 CONNECTOR x 3


## *Attaching to 5.25 inch Bay :*

---

1. Make sure your computer is powered off.
2. Insert the BFW3000 into 5.25 inch bay and fix it, as shown below.



3. Connect the 1394 cable to the PCI 1394 adapter.



4. Install the 1394 adapter into the PCI slot. Press down firmly until the card clicks into place. Then, screw down the bracket of 1394 adapter, as shown below.



5. Then finished.